



JAMES W. GIBSON
Oil & Gas Producer

May 20, 1998

State No. 15
NESW Section 15, T19S-R47W
Kiowa County, Colorado
Nee Noshe Field

H₂S Contingency Plan

1. Install elevated wind sock at location.
2. At location, have portable H₂S meter (ppm).
3. At location, have gas mask and oxygen pack equipment.

Caution to be exercised at all times and particularly after well is completed and being flow tested through separation equipment (flare line with riser for flare to be located minimum 200 ft. from separator-heater).

Note - The Marmaton in this well was successfully and safely flow tested 9/5/96 - 10/4/96.