

**Chevron**

1400 Smith St., RM 45096
Houston, TX 77002

P.O. Box 1979, Farmington, NM 87499
(505) 325-2627

Name: BASEBALL K11-19

API: 05-123-25461

Rig # 04

Well Plugging Report

Work Detail

Start	Stop	Activity
12:30 PM	01:30 PM	Rig move (11 mi) from (SHELTON RG26-08) to (BASEBALL K11-19).
01:30 PM	02:30 PM	HSM and JSA. Spot in equipment, RU, Pulling and pumping unit, RU, hard and hydraulic and hard lines.
02:30 PM	03:00 PM	Check well head pressure. SITP=1600#, SICP=1600#, SIBHP=20#. Check and test ground cables with ohm meter.
03:00 PM	04:00 PM	Prep 5k weatherford BOP, remove 3k A-plus BOP.
04:00 PM	05:00 PM	Drain and winterized all equipment. Clean and secured location. SDFD.
05:00 PM	05:30 PM	Crew travel to A-Plus yard in GREELEY CO.

DIRECTIONS RECEIVED 04/27/2023 @ 09:00 AM) (ROUTE SURVEY COMPLETED 04/27/2023)

Crew:

Title	Name	Hours	Vehicle
Supervisor:	Solis, David	05.0	20- Supervisor PU
Operator:	Romero, Fidel	05.0	52- Crew PU
Derrick Hand:	Medina, Jesus	05.0	
Floor hand:	Garcia, Gabriel	05.0	
Floor hand:	Klinger, DJ	05.0	
Floor hand:	Pelayo, Sebastian	05.0	

On Site Rep

Name	Association	Notes
Chavez, Edgar	Co. Rep.	On Location.

Equipment:

Dog house -DH-J	Pusher Trailer P-190
Base beam V-#2	Gas Buster #424
House -DH-J	PT500
	500 bbls Tank #418

Worked on Friday 04/28/2023

Hardline Trailer CS210
Wase Pit 575
Tubing trailer #108
Pump #214

**Chevron**

1400 Smith St., RM 45096
Houston, TX 77002

P.O. Box 1979, Farmington, NM 87499
(505) 325-2627

Name: BASEBALL K11-19

API: 05-123-25461

Rig # 04

Well Plugging Report

Work Detail

Start	Stop	Activity
05:30 AM	06:30 AM	Load supplies and equipment . Travel to location.
06:30 AM	07:00 AM	HSM and JSA. Service and start equipment.
07:00 AM	07:30 AM	Check well head pressure. SITP= #1550, SICP= #1550, SIBHP= #0. Check and test ground cables with ohm meter.
07:30 AM	08:30 AM	Pressure test BOP, pump line, manifold, 2-3/8" TIW V (2-3/8" pipe rams and blinds H/L) GOOD TEST
08:30 AM	12:00 PM	ND, well head RU, (SELECT) Attempt to flare well, fitting leaking on (SELECT) separator (Stand by).
12:00 PM	01:30 PM	Performed flaring operations.
01:30 PM	03:00 PM	Rig up pump to casing flared tubing to (SELECT) flare stack pumped 135 bbls total
03:00 PM	04:30 PM	RD, (SELECT), ND, well head NU, BOP, Test Connector and BOP H/L GOOD TEST: RU, work floor and prep tools for 2-3/8".
04:30 PM	05:30 PM	TOTH, with 42 stand, and LD 50 joints on tubing trailer.
05:30 PM	06:30 PM	Drain and winterized all equipment. Clean and secured location. SDFD.
06:30 PM	07:00 PM	Crew travel to A-Plus yard in GREELEY CO.

Crew:

Title	Name	Hours	Vehicle
Supervisor:	Solis, David	13.5	20- Supervisor PU
Operator:	Romero, Fidel	13.5	53- Crew PU
Derrick Hand:	Medina, Jesus	13.5	
Floor hand:	Garcia, Gabriel	13.5	
Floor hand:	Klinger, DJ	13.5	
Floor hand:	Pelayo, Sebastian	13.5	

On Site Rep

Name	Association	Notes
Chavez, Edgar	Co. Rep.	On Location.

Worked on Monday 05/01/2023

Equipment:

Base beam V-#2

Dog House -DH-J

Pushers Trailer P-190

Gas Buster #424

PT500

500 bbls Tank #418

Hardline Trailer CS210

Wase Pit #575

Tubing trailer #108

**Chevron**

1400 Smith St., RM 45096
Houston, TX 77002

P.O. Box 1979, Farmington, NM 87499
(505) 325-2627

Name: BASEBALL K11-19

API: 05-123-25461

Rig # 04

Well Plugging Report

Work Detail

Start	Stop	Activity
05:30 AM	06:30 AM	Load supplies and equipment . Travel to location.
06:30 AM	07:00 AM	HSM and JSA. Service and start equipment.
07:00 AM	07:30 AM	Check well head pressure. SICP= #100, SITP= #200 SIBHP= #0 Check and test ground cables with ohm meter.
07:30 AM	08:00 AM	Rig up pump to tubing and pumped 30 bbls.
08:00 AM	09:00 AM	TOTH, lay down 100 joints on tubing trailer.
09:00 AM	10:00 AM	HSM and JSA. RU, wireline pick up 4-1/2" CIBP RIH, and set @6878' POH, lay down setting tool.
10:00 AM	10:30 AM	Rig up pump to casing load 4-1/2" casing 1BPM with 30 bbls total, performed a pressure test @1500psi 4-1/2" casing, 4-1/2" CIBP GOOD TEST:
10:30 AM	11:30 AM	Plug # 1 (NIO)-RIH, dump bail, 2 sxs total. 15.8 ppg, 1.15 yield 2.3 cuft, 2.0 bbl slurry, class "G" cement, mix factor of 5.0, ph level 7.0 chloride level 0.0. Water Temperature 78 degrees, from 6878'KB to 6852'KB. ETOC @ 6852'KB. POOH, lay down dump bail.
11:30 AM	01:00 PM	Pick up CBL tool RIH, CBL from 4500' to surface LD, CBL tool RD, wireline.
01:00 PM	02:00 PM	Drain and winterized all equipment. Clean and secured location. SDFD.
02:00 PM	02:30 PM	Crew travel to A-Plus yard in GREELEY CO.

Crew:

Title	Name	Hours	Vehicle
Supervisor:	Solis, David	09.0	20- Supervisor PU
Operator:	Romero, Fidel	09.0	52- Crew PU
Derrick Hand:	Medina, Jesus	09.0	
Floor hand:	Garcia, Gabriel	09.0	
Floor hand:	Klinger, DJ	09.0	
Floor hand:	Pelayo, Sebastian	09.0	

On Site Rep

Name	Association	Notes
------	-------------	-------

Chavez, Edgar

Co. Rep.

Worked on Tuesday 05/02/2023
On Location.

Equipment:

Base beam V-#2

Dog House -DH-J

Pushers Trailer P-190

Gas Buster #424

PT500

500 bbls Tank #418

Hardline Trailer CS210

Wase Pit #575

Tubing trailer #108

Accumalator #2064483

BOP #8880



Chevron

1400 Smith St., RM 45096
Houston, TX 77002

P.O. Box 1979, Farmington, NM 87499
(505) 325-2627

Name: BASEBALL K11-19

API: 05-123-25461

Rig # 04

Well Plugging Report

Work Detail

Start	Stop	Activity
05:30 AM	06:30 AM	Load supplies and equipment . Travel to location.
06:30 AM	07:00 AM	HSM and JSA. Service and start equipment.
07:00 AM	07:30 AM	Check well head pressure. SICP= 0#, SITP= 0#, SIBHP= 0#. Check and test ground cables with ohm meter.
07:30 AM	08:30 AM	HSM and JSA. RU, wireline pick up 4-1/2" CIBP RIH, and set @4099' POH, lay down setting tool
08:30 AM	09:00 AM	Plug # 2 (SUSSEX)-RIH, dump bail, 2 sxs total. 15.8 ppg, 1.15 yield 2.3 cuft, 2.0 bbl slurry, class "G" cement, mix factor of 5.0, ph level 7.0 chloride level 0.0. Water Temperature 77 degrees, from @4099'KB to 4073'KB. ETOC @ 4073'KB. POOH, lay down dump bail.
09:00 AM	09:30 AM	pick up 4-1/2" CIBP RIH, and set @2268' POH, lay down setting tool, RD, wireline.
09:30 AM	10:00 AM	TITH, with 36 stands pick up 2 joint from tubing trailer to tag CIBP @2268'. LD, 1 joint pick up 10' sub.
10:00 AM	10:30 AM	Plug # 3 (COURTESY)- Mixed and pumped, 10 sxs total. 15.8 ppg, 1.15 yield 11.5 cuft, 2.0 bbl slurry, class "G" cement, mix factor of 5.0, ph level 7.0 chloride level 0.0. Water Temperature 78 degrees, 1.1 mix water from @2268'KB to 2137'KB. ETOC @ 2137'KB.
10:30 AM	11:30 AM	TOTH, lay 10' sub and 73 joints on tubing trailer.
11:30 AM	12:00 PM	RU, wireline pick up 1' 6 spf guns and perforate production casing @760', POH, lay down gun RD, wireline.
12:00 PM	05:00 PM	Rig up pump to casing to stablish circulation out of surface, attempted to pump was not able due to leak on surface casing, (STAND BY) for (CHEVRON) decision, Stand by for (FORTRESS) water truck to suck out water from water burm on well head.
05:00 PM	05:30 PM	Pumped down casing out surface 60 bbls total.
05:30 PM	06:30 PM	Plug # 4 (SURFACE)-MIXED and pumped, 160 sxs total. 60.0 sxs on 9"OH, 70 sxs on 8-5/8", 30.0 sxs on 4-1/2" casing, 15.8 ppg, 1.15 yield 184.0 cuft, 32.7 bbl slurry, class "G" cement, mix factor of 5.0, ph level 7.0 chloride level 0.0. Water Temperature 79 degrees, 19.0 mix of water, from 760'KB to surface, ETOC SURFACE.
06:30 PM	07:30 PM	RD, work floor ND, BOP RU, master valve.
07:30 PM	08:00 PM	Clean and secured location. SDFD.
08:00 PM	08:30 PM	Crew travel to A-Plus yard in GREELEY CO.

Crew:

Title	Name	Hours	Vehicle
Supervisor:	Solis, David	15.0	20- Supervisor PU
Operator:	Romero, Fidel	15.0	52- Crew PU
Derrick Hand:	Medina, Jesus	15.0	
Floor hand:	Garcia, Gabriel	15.0	
Floor hand:	Klinger, DJ	15.0	
Floor hand:	Pelayo, Sebastian	15.0	

On Site Rep

Name	Association	Notes
Chavez, Edgar	Co. Rep.	On Location.

Equipment:

Base beam V-#2
Dog House -DH-J
Pushers Trailer P-190
Gas Buster #424
PT500
500 bbls Tank #418
Hardline Trailer PCS210
Wase Pit #575
Cement Truck 143
Tubing trailer #108
Bulk truck #555 (stand by #335)

**Chevron**

1400 Smith St., RM 45096
Houston, TX 77002

P.O. Box 1979, Farmington, NM 87499
(505) 325-2627

Name: BASEBALL K11-19

API: 05-123-25461

Rig # 04

Well Plugging Report

Work Detail

Start	Stop	Activity
05:30 AM	06:30 AM	Load supplies and equipment . Travel to location.
06:30 AM	07:00 AM	HSM and JSA. Service and start equipment.
07:00 AM	07:30 AM	Check well head pressure. SICP 0#, SITP 0#, SIBHP 0# Check and test ground cables with ohm meter.
07:30 AM	08:00 AM	RD, pulling and pumping unit, RD, hard lines and hydraulic lines.
08:00 AM	09:30 AM	Prep equipment and trailers for rig move, Wash gas buster tank.

(NOTES: TAGGED AT 16' SURFACE PLUG.)

Crew:

Title	Name	Hours	Vehicle
Supervisor:	Solis, David	04.0	20- Supervisor PU
Operator:	Romero, Fidel	04.0	52- Crew PU
Derrick Hand:	Medina, Jesus	04.0	
Floor hand:	Garcia, Gabriel	04.0	
Floor hand:	Klinger, DJ	04.0	
Floor hand:	Pelayo, Sebastian	04.0	

On Site Rep

Name	Association	Notes
Chavez, Edgar	Co. Rep.	On Location.

Equipment:

Base beam V-#2	Wase Pit #575
Dog House -DH-J	Cement Truck #555 #335
Pushers Trailer P-190	Tubing trailer #108
Gas Buster #424	
PT500	
500 bbls Tank #418	
Hardline Trailer PCS210	