

State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 (303) 894-2100 Fax: (303) 894-2109



FOR OGCC USE ONLY

**BRADENHEAD TEST REPORT**

Step 1. Record all tubing and casing pressures as found.  
Step 2. Sample now, if intermediate or surface casing pressure >25 psi. In sensitive areas, 1 psi.  
Step 3. Conduct Bradenhead test.  
Step 4. Conduct intermediate casing test.  
Step 5. Send report to BLM within 30 days and to OGCC within 10 days. Include wellbore diagram if not previously submitted or if wellbore configuration has changed since prior program. Attach gas and liquid analyses if sampled.

1. OGCC Operator Number: \_\_\_\_\_  
 2. Name of Operator: T-Rex  
 3. BLM Lease No: No  
 4. API Number: \_\_\_\_\_ 5. Multiple completion?  Yes  No  
 6. Well Name: Pearria Number: #36  
 7. Location (Dir/Qtz, Sec, Twp, Rng, Meridian): \_\_\_\_\_  
 8. County: Arapahoe 9. Field Name: \_\_\_\_\_  
 10. Minerals:  Fee  State  Federal  Indian

11. Date of Test: \_\_\_\_\_  
 12. Well Status:  Flowing  Shut In  
 Gas Lift  Pumping  Injection  
 Clock/Intermitter  Plunger Lift  
 13. Number of Casing Strings:  Two  Three  Liner?

14. **STEP 1: EXISTING PRESSURES**

Record all pressures as found	Tubing: <u>65#</u> Fm: <u>J-sand</u>	Tubing: _____ Fm: _____	Prod. Casing: <u>65#</u> Fm: <u>J-sand</u>	Intermediate Cag: _____	Surface Casing: <u>0</u>
-------------------------------	---	----------------------------	---	-------------------------	--------------------------

16. **STEP 2: See instructions above.**

16. **STEP 3: BRADENHEAD TEST**

With gauges monitoring production, intermediate casing and tubing pressures, open surface casing (bradenhead) valve (if no intermediate casing, monitor only the production casing and tubing pressures.) Record pressures at five minute intervals. Define characteristics of flow in "Bradenhead Flow" column using letter designations below:  
 O = No Flow; C = Continuous; D = Down to 0; V = Vapor  
 H = Water H2O; M = Mud; W = Whisper; S = Surge; G = Gas

Elapsed Time (Min:Sec)	Fm: <u>J-sand</u> Tubing:	Fm: _____ Tubing:	Production Casing PSIG	Intermediate Casing PSIG	Bradenhead Flow:
00:					
8:00:17	<u>65#</u>		<u>65#</u>		<u>-0-</u>
05:					
8:05	<u>65#</u>		<u>65#</u>		<u>-0-</u>
10:					
8:10	<u>65#</u>		<u>65#</u>		<u>-0-</u>
15:					
8:15	<u>65#</u>		<u>65#</u>		<u>-0-</u>
20:					
8:20	<u>65#</u>		<u>65#</u>		<u>-0-</u>
25:					
8:25	<u>65#</u>		<u>65#</u>		<u>-0-</u>
30:					
8:30	<u>65#</u>		<u>65#</u>		<u>-0-</u>
					Note instantaneous Bradenhead PSIG at end of test: <u>-0-</u>

BRADENHEAD SAMPLE TAKEN?  Yes  No  Gas  Liquid  
 Character of Bradenhead fluid:  Clear  Fresh  Sulfur  Salty  Black  
 Other: (describe) None  
 Sample cylinder number: \_\_\_\_\_

17. **STEP 4: INTERMEDIATE CASING TEST**

With gauges monitoring production casing and tubing pressures, open the intermediate casing valve. Record pressures at five minute intervals. Characterize flow in "Intermediate Flow" column using letter designations below:  
 O = No Flow; C = Continuous; D = Down to 0; V = Vapor  
 H = Water H2O; M = Mud; W = Whisper; S = Surge; G = Gas

Elapsed Time (Min:Sec)	Fm: _____ Tubing:	Fm: _____ Tubing:	Production Casing PSIG	Intermediate Casing PSIG	Intermediate Flow:
00:					
05:					
10:					
15:					
20:					
25:					
30:					
					Note instantaneous Intermediate Casing PSIG at end of test: >

INTERMEDIATE SAMPLE TAKEN?  Yes  No  Gas  Liquid  
 Character of Intermediate fluid:  Clear  Fresh  Sulfur  Salty  Black  
 Other: (describe) \_\_\_\_\_  
 Sample cylinder number: \_\_\_\_\_

18. Comments: \_\_\_\_\_

19. **STEP 5: See instructions above.**

I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct, and complete.  
 Test Performed by: Vic Behrens Title: Lease Operator Phone: 303-810-6382  
 Signed: Vic Behrens Title: \_\_\_\_\_ Date: 12-28-2023  
 WITNESSED BY: \_\_\_\_\_ Title: \_\_\_\_\_ Agency: \_\_\_\_\_