



<div>FORM 6</div> <div>Rev 11/20</div>	<div>State of Colorado</div> <div>Energy & Carbon Management Commission</div> <div>1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109</div>	<div></div>	<table><tr><td>DE</td><td>ET</td><td>OE</td><td>ES</td></tr></table>	DE	ET	OE	ES																													
	DE	ET	OE	ES																																
<div>WELL ABANDONMENT REPORT</div> <div><p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p></div>			<div>Document Number: 403708070</div> <div>Date Received:</div>																																	
<div><div>ECMC Operator Number: 10779</div><div>Contact Name: Jared Ede</div><div>Name of Operator: SCOUT ENERGY MANAGEMENT LLC</div><div>Phone: (856) 454-6259</div><div>Address: 13800 MONTFORT DRIVE SUITE 100</div><div>Fax:</div><div>City: DALLAS State: TX Zip: 75240</div><div>Email: Jared.Ede@scoutep.com</div><div>For "Intent" 24 hour notice required, Name: Burchett, Kirby Tel: (970) 852-9642</div><div>ECMC contact: Email: kirby.burchett@state.co.us</div></div>																																				
<div>Type of Well Abandonment Report: <input checked="" type="checkbox"/> Notice of Intent to Abandon <input type="checkbox"/> Subsequent Report of Abandonment</div>																																				
<div><div>API Number 05-103-07666-00</div><div>Well Name: EMERALD Well Number: 160</div><div>Location: QtrQtr: SESW Section: 36 Township: 2N Range: 103W Meridian: 6</div><div>County: RIO BLANCO Federal, Indian or State Lease Number:</div><div>Field Name: RANGELY Field Number: 72370</div></div>																																				
<div>Only Complete the Following Background Information for Intent to Abandon</div> <div><div>Latitude: 40.099645 Longitude: -108.908957</div><div>GPS Data: GPS Quality Value: Type of GPS Quality Value: Date of Measurement:</div><div>Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems</div><div><input checked="" type="checkbox"/> Other Re-plugging Dry hole - Well originally P&A'ed in 1974</div><div>Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Estimated Depth: 78</div><div>Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Details:</div></div>																																				
<div>Current and Previously Abandoned Zones</div> <table><tr><th>Formation</th><th>Perf. Top</th><th>Perf. Btm</th><th>Abandoned Date</th><th>Method of Isolation</th><th>Plug Depth</th></tr><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr></table> <div>Total: 0 zone(s)</div>				Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																											
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																															
<div>Casing History</div> <table><tr><th>Casing Type</th><th>Size of Hole</th><th>Size of Casing</th><th>Grade</th><th>Wt/Ft</th><th>Csg/Liner Top</th><th>Setting Depth</th><th>Sacks Cmt</th><th>Cmt Btm</th><th>Cmt Top</th><th>Status</th></tr><tr><td>SURF</td><td>10</td><td>7</td><td>unk</td><td>unk</td><td>0</td><td>31</td><td></td><td>31</td><td>0</td><td>VISU</td></tr><tr><td>OPEN HOLE</td><td>10</td><td></td><td></td><td></td><td>31</td><td>78</td><td></td><td></td><td></td><td></td></tr></table>				Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	10	7	unk	unk	0	31		31	0	VISU	OPEN HOLE	10				31	78				
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																										
SURF	10	7	unk	unk	0	31		31	0	VISU																										
OPEN HOLE	10				31	78																														

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 19 sks cmt from 4 ft. to 78 ft. Plug Type: OPEN HOLE Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

Originally P&A'ed in 1974 w/cuttings filled to bottom of 7" casing topped with 5 sxs cement.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Anita Sanford
Title: Sr. Regulatory Analyst Date: _____ Email: anita.sanford@scoutep.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type **Description**

0 COA

Attachment List

Att Doc Num

Name

403708104	PROPOSED PLUGGING PROCEDURE
403708105	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)