



<div>FORM</div> <div>6</div> <div>Rev 11/20</div>	<div>State of Colorado</div> <div>Energy & Carbon Management Commission</div> <div>1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109</div>	<div></div>	<table><tr><td>DE</td><td>ET</td><td>OE</td><td>ES</td></tr></table>	DE	ET	OE	ES																													
	DE	ET	OE	ES																																
<div>WELL ABANDONMENT REPORT</div> <div><p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p></div>			<div>Replug By Other Operator</div> <div>Document Number: 403984402</div> <div>Date Received:</div>																																	
<div><div>ECMC Operator Number: 47120</div><div>Contact Name: Candice Barber</div><div>Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP</div><div>Phone: (307) 233-4513</div><div>Address: P O BOX 173779</div><div>Fax:</div><div>City: DENVER State: CO Zip: 80217-</div><div>Email: candice_barber@oxy.com</div><div>For "Intent" 24 hour notice required, Name: Tel:</div><div>ECMC contact: Email:</div></div>																																				
<div>Type of Well Abandonment Report: <input type="checkbox"/> Notice of Intent to Abandon <input checked="" type="checkbox"/> Subsequent Report of Abandonment</div>																																				
<div><div>API Number 05-123-08586-00</div><div>Well Name: FRANK Well Number: 1</div><div>Location: QtrQtr: NENE Section: 33 Township: 4N Range: 67W Meridian: 6</div><div>County: WELD Federal, Indian or State Lease Number:</div><div>Field Name: WATTENBERG Field Number: 90750</div></div>																																				
<div>Only Complete the Following Background Information for Intent to Abandon</div> <div><div>Latitude: 40.273378 Longitude: -104.888706</div><div>GPS Data: GPS Quality Value: 1.2 Type of GPS Quality Value: PDOP Date of Measurement: 10/24/2024</div><div>Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems</div><div><input type="checkbox"/> Other</div><div>Casing to be pulled: <input type="checkbox"/> Yes <input type="checkbox"/> No Estimated Depth:</div><div>Fish in Hole: <input type="checkbox"/> Yes <input type="checkbox"/> No If yes, explain details below</div><div>Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input type="checkbox"/> No If yes, explain details below</div><div>Details:</div></div>																																				
<div>Current and Previously Abandoned Zones</div> <table><tr><th>Formation</th><th>Perf. Top</th><th>Perf. Btm</th><th>Abandoned Date</th><th>Method of Isolation</th><th>Plug Depth</th></tr><tr><td></td><td></td><td></td><td></td><td></td><td></td></tr></table> <div>Total: 0 zone(s)</div>				Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																											
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																															
<div>Casing History</div> <table><tr><th>Casing Type</th><th>Size of Hole</th><th>Size of Casing</th><th>Grade</th><th>Wt/Ft</th><th>Csg/Liner Top</th><th>Setting Depth</th><th>Sacks Cmt</th><th>Cmt Btm</th><th>Cmt Top</th><th>Status</th></tr><tr><td>SURF</td><td>12+1/4</td><td>8+5/8</td><td>J-55</td><td>24</td><td>0</td><td>339</td><td>300</td><td>339</td><td>0</td><td>VISU</td></tr><tr><td>1ST</td><td>7+7/8</td><td>4+1/2</td><td>I-80</td><td>11.6</td><td>0</td><td>7850</td><td>290</td><td>7850</td><td>7018</td><td>VISU</td></tr></table>				Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	12+1/4	8+5/8	J-55	24	0	339	300	339	0	VISU	1ST	7+7/8	4+1/2	I-80	11.6	0	7850	290	7850	7018	VISU
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																										
SURF	12+1/4	8+5/8	J-55	24	0	339	300	339	0	VISU																										
1ST	7+7/8	4+1/2	I-80	11.6	0	7850	290	7850	7018	VISU																										

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 178 with 65 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>285</u> sks cmt from <u>5440</u> ft. to <u>4786</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>285</u> sks cmt from <u>4326</u> ft. to <u>3880</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>285</u> sks cmt from <u>2175</u> ft. to <u>1530</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set <u>285</u> sks cmt from <u>1383</u> ft. to <u>889</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 375 sacks half in. half out surface casing from 670 ft. to 178 ft. Plug Tagged: ☒

Set 65 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: 192
Surface Plug Setting Date: 04/15/2024 Cut and Cap Date: 10/24/2024

*Wireline Contractor: NEXTIER *Cementing Contractor: AXIS

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Candice Barber
Title: REG ANALYST Date: _____ Email: DJREGULATORY@OXY.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

COA Type	Description
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
403984449	OPERATIONS SUMMARY
403984452	CEMENT JOB SUMMARY
403984453	OTHER
403984454	WELLBORE DIAGRAM
403984456	WIRELINE JOB SUMMARY

Total Attach: 5 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)