

Flowline Abandonment Type:

Partial Abandon in Place to area of conflict due to OOS flowline crossing and due to facility.

Flowlines

- Abandoned
- Active
- Out of Service
- Pre-commissioned
- Removed
- Turned into Air Line
- Area of Conflict (Proposed Abandon-in-Place Area)
- ✕ Proposed Soil Sample Location
- Field Screening Location

Wells

- Active
- ✕ Abandoned Location
- Dry & Abandoned
- ✖ Plugged & Abandoned
- ⊙ Producing
- ✖ Shut-In
- Temporarily Abandoned

Third-Party Pipelines

- — —
- — —
- — —
- — —
- — —
- — —
- NWI Wetlands

