

Replug By Other Operator

Document Number:
404305078

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 47120 Contact Name: Candice Barber

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (307) 233-4513

Address: P O BOX 173779 Fax: _____

City: DENVER State: CO Zip: 80217- Email: candice_barber@oxy.com

For "Intent" 24 hour notice required, Name: _____ Tel: _____

ECMC contact: Email: _____

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-13237-00

Well Name: CERVI Well Number: 34-1

Location: QtrQtr: CSW Section: 34 Township: 3N Range: 63W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.177922 Longitude: -104.427995

GPS Data: GPS Quality Value: 1.4 Type of GPS Quality Value: PDOP Date of Measurement: 08/01/2025

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J-55	24	0	435	300	435	0	VISU
OPEN HOLE	7+7/8				435	7268				

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	50	sks cmt from	7118	ft. to	6980	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input type="checkbox"/>
Set	200	sks cmt from	6509	ft. to	5660	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	281	sks cmt from	4413	ft. to	3632	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	211	sks cmt from	2606	ft. to	2187	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	293	sks cmt from	1606	ft. to	745	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>

Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth

(Cast Iron Cement Retainer Depth)

Set 405 sacks half in. half out surface casing from 712 ft. to 0 ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing
Surface Plug Setting Date: 07/21/2025 Cut and Cap Date: 08/01/2025 Number of Days from Setting Surface Plug to Capping or Sealing the Well: 11

*Wireline Contractor: _____ *Cementing Contractor: SLB

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Candice Barber
Title: REG ANALYST Date: _____ Email: DJREGULATORY@OXY.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

<u>COA Type</u>	<u>Description</u>
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
404305081	OPERATIONS SUMMARY
404305082	CEMENT JOB SUMMARY
404305083	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)