

Replug By Other Operator

Document Number:
404382540

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 10670 Contact Name: Alison Parker
 Name of Operator: BISON IV OPERATING LLC Phone: (918) 859-9007
 Address: 518 17TH STREET SUITE 1800 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: aparker@bisonog.com

For "Intent" 24 hour notice required, Name: _____ Tel: _____
 Email: _____

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-05364-00
 Well Name: CHILDS Well Number: 1
 Location: QtrQtr: NESE Section: 14 Township: 7N Range: 60W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WILDCAT Field Number: 99999

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.573401 Longitude: -104.052905
 GPS Data: GPS Quality Value: 1.2 Type of GPS Quality Value: PDOP Date of Measurement: 06/21/2025

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	NA	26	0	112	50	112	0	VISU
OPEN HOLE	7+7/8				112	6960				

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	40	sks cmt from	6920	ft. to	6780	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input type="checkbox"/>
Set	100	sks cmt from	6107	ft. to	5767	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input type="checkbox"/>
Set	75	sks cmt from	1529	ft. to	1271	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	170	sks cmt from	520	ft. to	294	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	115	sks cmt from	294	ft. to	170	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>

Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at	_____	ft. with	_____	sacks. Leave at least 100 ft. in casing	_____	CICR Depth

(Cast Iron Cement Retainer Depth)

Set 70 sacks half in. half out surface casing from 170 ft. to 0 ft. Plug Tagged:
Set 5 sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing
Surface Plug Setting Date: 08/07/2025 Cut and Cap Date: 09/10/2025 Number of Days from Setting Surface Plug to Capping or Sealing the Well: 34

*Wireline Contractor: N/A *Cementing Contractor: Axis Energy Services

Type of Cement and Additives Used: 15.8 # (1.15 ft³/sk) G Neat cement w/2% CaCl₂

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Plug from 6780'-6920' remains from OG P&A

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Alison Parker
Title: Regulatory Analyst Date: _____ Email: aparker@bisonog.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

<u>COA Type</u>	<u>Description</u>
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
404382716	OPERATIONS SUMMARY
404382724	CEMENT JOB SUMMARY
404382727	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)