

DE	ET	OE	ES
----	----	----	----

Replug By Other Operator
 Document Number:
 404479016
 Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 10670 Contact Name: Alison Parker
 Name of Operator: BISON IV OPERATING LLC Phone: (918) 859-9007
 Address: 518 17TH STREET SUITE 1800 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: aparker@bisonog.com
For "Intent" 24 hour notice required, Name: Petrie, Erica Tel: (303) 726-3822
ECMC contact: Email: erica.petrie@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment
 API Number 05-123-11894-00
 Well Name: BEHRING Well Number: 42-1
 Location: QtrQtr: SENE Section: 1 Township: 5N Range: 61W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WILDCAT Field Number: 99999

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.432477 Longitude: -104.148872
 GPS Data: GPS Quality Value: _____ Type of GPS Quality Value: _____ Date of Measurement: _____
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other Offset Frac Reentry
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	NA	24	0	224	180	224	0	VISU
OPEN HOLE	7+7/8					6688				

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set <u>32</u> sks cmt from <u>6608</u> ft. to <u>6508</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input type="checkbox"/>
Set <u>100</u> sks cmt from <u>6018</u> ft. to <u>5718</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input type="checkbox"/>
Set <u>32</u> sks cmt from <u>1506</u> ft. to <u>1406</u> ft.	Plug Type: <u>OPEN HOLE</u>	Plug Tagged: <input checked="" type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>
Set _____ sks cmt from _____ ft. to _____ ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing	_____	CICR Depth

(Cast Iron Cement Retainer Depth)

Set 86 sacks half in. half out surface casing from 274 ft. to 0 ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing
 Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Alison Parker
 Title: Regulatory Analyst Date: _____ Email: aparker@bisonog.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

COA Type	Description
0 COA	

ATTACHMENT LIST

Att Doc Num	Name
404479042	WELLBORE DIAGRAM
404479047	PROPOSED PLUGGING PROCEDURE
404491720	SURFACE OWNER CONSENT
404491721	LOCATION PHOTO

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Permit	RTD-Operator's Request	12/18/2025

Total: 1 comment(s)