



DE	ET	OE	ES
Document Number: 404496605			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

ECMC Operator Number: 10633 Contact Name: Chris Ogonna
 Name of Operator: CRESTONE PEAK RESOURCES OPERATING LLC Phone: (303) 2939100
 Address: 555 17TH STREET SUITE 3700 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: cogbonna@civiresources.com

For "Intent" 24 hour notice required, Name: Peterson, Tom Tel: (970) 370-1281
 Email: tom.peterson@state.co.us

ECMC contact:

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-07324-00
 Well Name: KAWAKAMI Well Number: 1
 Location: QtrQtr: SENE Section: 35 Township: 3N Range: 67W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: 63067
 Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.185343 Longitude: -104.852822
 GPS Data: GPS Quality Value: 1.8 Type of GPS Quality Value: PDOP Date of Measurement: 05/13/2009

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other P&A well on OOSPL

Casing to be pulled: Yes No Estimated Depth: 3000
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7327	7344			
J SAND	7760	7813			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	NA	24		160	160	160	0	VISU
1ST	7+7/8	4+1/2	NA	11.6		7882	250	7882	7861	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7665 with 2 sacks cmt on top. CIBP #2: Depth 7230 with 22 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 16 sks cmt from 5200 ft. to 5000 ft. Plug Type: CASING Plug Tagged:
Set 16 sks cmt from 4050 ft. to 3850 ft. Plug Type: CASING Plug Tagged:
Set 8 sks cmt from 3100 ft. to 3000 ft. Plug Type: CASING Plug Tagged:
Set 75 sks cmt from 3000 ft. to 2800 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 129 sacks half in. half out surface casing from 398 ft. to 0 ft. Plug Tagged:
Set 10 sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Proposed WBD Attached.
This location is not within a HPH area. CPW consultation not required.
Unable to confirm casing grade with historical documentation (used N/A).
Operator will use secondary containment for all tanks and other liquid containment.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Mandie Flinn
Title: Engineering Tech Date: _____ Email: dlabandonment@civiresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

<u>COA Type</u>	<u>Description</u>
0 COA	

ATTACHMENT LIST

<u>Att Doc Num</u>	<u>Name</u>
404496606	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)