

Daily Operations

Well Name	Surface UWI	Primary Job Typ	Start Date	Summary
Pettinger 34-2	0512323591	Abandon Well - Temporary	8/7/2025	CREW AND EQUIP TO LOC. HELD SAFETY MTG. SPOTTED IN EQUIP AND RIG. RU PUMP AND TANK AND SELECT FLOW BACK. IWP 810/905# SURF 0# WAIT ON PROCEDURE APPROVAL. TURNED WELL ON AND STARTED FLARING OFF GAS. PUMPED 60 DOWN CSG AND RETRIEVED PLUNGER. CSG ON VACUUM TRIED TO PUMP DOWN TBG AND AT 10 BBLs TBG PRESSURED UP TO 1000#. BLEED OFF PSI MONITOR WELL FOR 30 MIN. WELL STATIC. RU AXIS 014. RD FLOW BACK. ND WH AND NU BOPS AND TEST. RU FLOOR. RU CORETECH SLICKLINE AND RETRIEVE DOWN HOLE TOOLS.
Pettinger 34-2	0512323591	Abandon Well - Temporary	8/8/2025	CREW TO LOCATION. HELD SAFETY MTG. IWP 0/0# SURF 0#. POOH W/TBG. RU WIRELINE AND TIH W/CIBP. SET AT 6905' DB 2 SKS CMT ON CIBP. POOH. RD WIRELINE LOAD CSG AND TEST TO 1500# GOOD TEST NO LOSS IN PSI. ND BOPS AND CHG OUT 3K WH TO 5K WH. NU BOPS AND TEST WH TO 1500# GOOD TEST. TIH. CC WELL CLEAN OF OIL AND GAS. TEST WH TO 1500#. GOOD TEST. LAY DOWN EXTRA JTS. LAND TBG ND BOPS AND NU TOP FLANGE W/5K MASTER VALVE. SECURE WELL CLEAN UP LOC. RDMOL