



DATE	TIME	WELL NO.	LEASE	JOB TYPE	LOG
9/3	0700				ON LOC
	0705				Run 1/2" CBR mach setting tool
	0718				SET C/B @ 1000
	0740				FULL TEST TO 1500 PSI
	0853				SHUT DOWN FULL 6 STOPS
	0900				THRU F/OAY
9/3	0930				ON LOC
	0948				TIE IN TO TAG PLUG
	0803				TAGGED RETAINER (C/B) NO CMT
					IN TUB.
	0834				P.O.O.H. PULLED 8 STOPS SAME WEL
					TIE INTO TUB PRESS UP TO 1000 PSI
	0858				P.O.O.H.
	1047				OUT OF HOLE W/ SETTING TOOL
					CMTED UP 12 JTS TUBING AND
					SETTING TOOL WILL NOT NEED
					TENSION PICK THRU W/ TAG
	1415				MOVE TO THE 2-R-23
	1725				RUN 4 1/2 TENSION PKR
	1755				SET PKR @ 1214
	1758				FILL HOLE
	1803				CLOSE BY-PASS
	1805				START ACIO JOB
	1811				AND STARTED Flowing close off lines
					SHUT DOWN THRU W/ TAG
					THANKS
					RANDY