



Prairie Operating Co.
P&A Re-Entry

Wellname: **Hoffman #1**
Location: **NWSW S32-11N-62W**
GPS: **40.878771, -104.350132**
API: **05-123-05803**
Directions:

Prepared By: Max Trehus
Office Phone:
Cell Phone: 303-809-0679

WOV Superintendent: Luke Rodman
Phone: 406-890-4073

Surface Csg: 10-3/4" 32.75# set @ 265'
Prod. Csg: NA
TOC: NA
Perfs: NA

Contacts for Flare Notification (keep email for documentation)	
Fire District:	Grover
Fire Chief:	
Contact:	970-895-2237

Tubing: NA
PBSD: NA
Max Pressure:
KB: 10'

**Contact WOV Superintendent or Engineer
so they can notify ECMC**

Invoice Coding: Please sign/code all invoices to 879.xxx codes

Procedure:

- 1 MIRU
- 2 NU flanges and BOP
- 3 DO cmt surface plug
- 4 DO cmt plug at surface casing shoe estimated TOC 235'
- 5 Slide down and tag cmt plug at estimated TOC 7674'
- 6 Pump 60 sx balanced plug from 7200' to 7000'
- 7 WOC 4 Hours, tag top of balanced plug
- 8 Pump 60 sx balanced plug from 2600 to 2400'
- 9 WOC 4 hours, tag top of balanced plug
- 10 Ensure all fluid migration has ceased
- 11 Pump surface plug from 365' to surface, top off as necessary
- 12 RDMO