


BOWER 10-53 LOCATION MAP

Township 6 North, Range 67 West, 6th P.M.
Section 10: SW/4



1. Farm road running N/S on the west side of disturbed area.
2. Farm road running E/W 100' west of disturbed area.
3. Farm road 400' Northwest of disturbed area.