

Hornung Wells and Tank Battery Access Map
NWNW Section 28, T4N, R68W

Tank Battery

Hornung 21-28

Hornung 52-28

Hornung 11-28

CR 5

CR