

T1N, R66W, 6th P.M.

LEGEND:

- = SURFACE LOCATION.
- ◆ = ENTRY POINT.
- = BOTTOM HOLE LOCATION.
- ▲ = SECTION CORNERS LOCATED. (NAD 83)
- △ = SECTION CORNERS RE-ESTABLISHED. (Not Set on Ground.) (NAD 83)

NOTE:

Distances referenced on plat to section lines are perpendicular.

