

**FORM**  
**6**  
Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400474281

Date Received:

08/29/2013

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Leah Perkins  
 Name of Operator: NOBLE ENERGY INC Phone: (970) 286-5925  
 Address: 1625 BROADWAY STE 2200 Fax: (970) 304-5099  
 City: DENVER State: CO Zip: 80202 Email: Lperkins@nobleenergyinc.com

**For "Intent" 24 hour notice required,** Name: PRECUP, JIM Tel: (303) 726-3822  
**COGCC contact:** Email: james.precup@state.co.us

API Number 05-123-10476-00 Well Number: 1  
 Well Name: RHOADES  
 Location: QtrQtr: SWSW Section: 30 Township: 3N Range: 66W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.189960 Longitude: -104.827930  
 GPS Data:  
 Date of Measurement: 06/19/2006 PDOP Reading: 1.9 GPS Instrument Operator's Name: Paul Tappy  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: 2500  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7285	7301			
J SAND	7716	7792			

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	518	500	518	0	VISU
1ST	7+7/8	4+1/2	11.6	7,429	175	7,429	6,920	CBL
1ST LINER	4+1/2	2+7/8	6.5	8,036	22	8,036	7,050	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	10	sks cmt from	7892	ft. to	7616	ft.	Plug Type: CASING	Plug Tagged: <input checked="" type="checkbox"/>
Set	10	sks cmt from	7400	ft. to	7185	ft.	Plug Type: CASING	Plug Tagged: <input checked="" type="checkbox"/>
Set	30	sks cmt from	6550	ft. to	6450	ft.	Plug Type: STUB PLUG	Plug Tagged: <input type="checkbox"/>
Set	100	sks cmt from	2600	ft. to	2400	ft.	Plug Type: STUB PLUG	Plug Tagged: <input type="checkbox"/>
Set		sks cmt from		ft. to		ft.	Plug Type: _____	Plug Tagged: <input type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 250 sacks half in. half out surface casing from 620 ft. to 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Marilyn Tucker  
 Title: Base Prod Tech Date: 8/29/2013 Email: mtucker@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURN, DIANA Date: 9/14/2013

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 3/13/2014

COA Type	Description
	1) Provide 24 hour notice of MIRU to Jim Precup at 303-726-3822 or e-mail at James.Precup@state.co.us. 2) For 620' plug: pump plug and displace, if not circulated to surface - shut-in, WOC 4 hours and tag plug (must be 470' or shallower - place 10 sx at surface). Leave at least 100' cement in the casing for each plug. 3) Properly abandon flowlines as per Rule 1103.

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400474281	FORM 6 INTENT SUBMITTED
400474356	PROPOSED PLUGGING PROCEDURE
400474357	WELLBORE DIAGRAM
400474358	WELLBORE DIAGRAM

Total Attach: 4 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	SC Doc 1769131	9/14/2013 3:37:15 PM

Total: 1 comment(s)