

Document Number:  
400562655

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Cheryl Light  
 Name of Operator: NOBLE ENERGY INC Phone: (720) 929-6461  
 Address: 1625 BROADWAY STE 2200 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: cheryl.light@anadarko.com

**For "Intent" 24 hour notice required,** Name: MONTOYA, JOHN Tel: (970) 3974124  
**COGCC contact:** Email: john.montoya@state.co.us

API Number 05-123-16299-00 Well Number: 28-4P  
 Well Name: ARNDT  
 Location: QtrQtr: NWNW Section: 28 Township: 2N Range: 65W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.113498 Longitude: -104.673815  
 GPS Data:  
 Date of Measurement: 08/17/2007 PDOP Reading: 1.9 GPS Instrument Operator's Name: Paul Tappy  
 Reason for Abandonment:  Dry     Production for Sub-economic     Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes     No    Estimated Depth: 1200  
 Fish in Hole:  Yes     No    If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	7683	7716		B PLUG CEMENT TOP	
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	908	300	908	0	VISU
1ST	7+7/8	4+1/2	11.6	8,070	400	8,070	6,326	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7620 with 2 sacks cmt on top. CIPB #2: Depth 6870 with 30 sacks cmt on top.  
 CIBP #3: Depth 100 with 23 sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 5110 ft. with 425 sacks. Leave at least 100 ft. in casing 4335 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 175 sacks half in. half out surface casing from 1300 ft. to 700 ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

This well is being transferred from Noble Energy to Anadarko. Form 10 has been submitted but not processed at this time. If there are any questions regarding the procedure please contact Cheryl Light at Anadarko (720) 929-6461.

Wellbore diagram and plugging procedure are attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Johnson  
 Title: Completions Supervisor Date: \_\_\_\_\_ Email: cheryljohnson@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400562659	PROPOSED PLUGGING PROCEDURE
400562660	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)