

FORM
6

Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400567688

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT
 Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM
For "Intent" 24 hour notice required, Name: Carlile, Craig Tel: (303) 8942100
COGCC contact: Email: craig.carlile@state.co.us

API Number 05-123-07852-00
 Well Name: EDWARD RADEMACHER UNIT Well Number: 1
 Location: QtrQtr: NWSW Section: 25 Township: 3N Range: 68W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.194220 Longitude: -104.956030
 GPS Data:
 Date of Measurement: 03/30/2006 PDOP Reading: 6.0 GPS Instrument Operator's Name: HORSESHOE
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: Squeeze holes exist at 570' and 4802'. A 350 sx sqz job was performed 1/30/1995 to plug hole in production casing. Cement estimated to be 10' - 586'. Another 150 sx sqz job was performed 10/2/2002 to plug a hole in the production casing at 4802'. Cement estimated to be 4800' - 4300'. Will run a CBL to verify cement coverages during plug & abandoning job.

Current and Previously Abandoned Zones

<u>Formation</u>	<u>Perf. Top</u>	<u>Perf. Btm</u>	<u>Abandoned Date</u>	<u>Method of Isolation</u>	<u>Plug Depth</u>
CODELL	7222	7244			
J SAND	7660	7680			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	218	200	220	0	VISU
1ST	7+7/8	4+1/2	10.5/11.6	7,804	200	7,803	6,968	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7580 with 2 sacks cmt on top. CIPB #2: Depth 7152 with 2 sacks cmt on top.

CIBP #3: Depth 100 with 10 sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.

CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 6540 ft. with 140 sacks. Leave at least 100 ft. in casing 6570 CICR Depth

Perforate and squeeze at 3910 ft. with 280 sacks. Leave at least 100 ft. in casing 3940 CICR Depth

Perforate and squeeze at 606 ft. with 240 sacks. Leave at least 100 ft. in casing 636 CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Perforate and squeeze at 6940 / 6540 ft. with 140 sacks Leave at least 100 ft. in casing 6570 CICR Depth
 Perforate and squeeze at 4290 / 3910 ft. with 280 sacks Leave at least 100 ft. in casing 3940 CICR Depth
 Perforate and squeeze at 953 / 606 ft. with 240 sacks Leave at least 100 ft. in casing 636 CICR Depth

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST Date: _____ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type	Description

Attachment Check List

Att Doc Num

Name

400567692	PROPOSED PLUGGING PROCEDURE
400567693	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)