

FORM
6

Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 400579578			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>68710</u>	Contact Name: <u>Andy Peterson</u>
Name of Operator: <u>PETERSON ENERGY OPERATING INC</u>	Phone: <u>(970) 203-4263</u>
Address: <u>2154 W EISENHOWER BLVD</u>	Fax: <u>(970) 669-4077</u>
City: <u>LOVELAND</u> State: <u>CO</u> Zip: <u>80537</u>	Email: <u>andy@petersonenergyoperating.com</u>
For "Intent" 24 hour notice required, Name: <u>JOHNSON, RANDELL</u> Tel: <u>(303) 815-9641</u>	
COGCC contact: Email: <u>randell.johnson@state.co.us</u>	

API Number <u>05-123-11392-00</u>	Well Number: <u>1</u>
Well Name: <u>ANSELM I</u>	
Location: QtrQtr: <u>NESW</u> Section: <u>31</u> Township: <u>2N</u> Range: <u>68W</u> Meridian: <u>6</u>	
County: <u>WELD</u> Federal, Indian or State Lease Number: _____	
Field Name: <u>SPINDLE</u> Field Number: <u>77900</u>	

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.092986 Longitude: -105.048775

GPS Data:
Date of Measurement: 05/28/2009 PDOP Reading: 2.4 GPS Instrument Operator's Name: Joseph Dugan

Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 4100

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SUSSEX	4385	4413			
SHANNON	4818	4836	03/01/1993	BRIDGE PLUG	4700
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	710	575	710	0	VISU
1ST	7+7/8	4+1/2	11.6	4,970	210	4,970	4,180	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 4000 ft. to 4150 ft. Plug Type: STUB PLUG Plug Tagged:
 Set 20 sks cmt from 0 ft. to 60 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 4385 ft. with 50 sacks. Leave at least 100 ft. in casing 4350 CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 60 sacks half in. half out surface casing from 600 ft. to 800 ft. Plug Tagged:
 Set 20 sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:
 Plan to squeeze Sussex perms under CICR set @ 4350' w/ 50 sx cement, cut off 4 1/2" casing @ 4100', set 50 sx stub plug, set 60 sx plug base of surface & tag, set 20 sx at surface, cut off & weld on plate.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.
 Signed: _____ Print Name: Andy Peterson
 Title: President Date: _____ Email: andy@petersonenergyoperating.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.
 COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type	Description

Attachment Check List

Att Doc Num	Name
400579581	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)