

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401279468

Date Received:

05/10/2017

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: DOREEN GREEN

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP

Phone: (970) 336-3517

Address: P O BOX 173779

Fax:

City: DENVER State: CO Zip: 80217-

Email: DOREEN.GREEN@ANADAKRO.COM

For "Intent" 24 hour notice required,

Name: Carlile, Craig

Tel: (970) 629-8279

COGCC contact:

Email: craig.carlile@state.co.us

API Number 05-123-18821-00

Well Name: HSR-SEKICH

Well Number: 10-17

Location: QtrQtr: NWSE Section: 17 Township: 3N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.224000

Longitude: -104.911050

GPS Data:

Date of Measurement: 08/31/2006

PDOP Reading: 2.5

GPS Instrument Operator's Name: Steve Fisher

Reason for Abandonment: ☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 4210

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7152	7164			
NIOBRARA	6950	6954			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	23	710	500	710	0	VISU
1ST	7+7/8	3+1/2	7.7	7,294	200	7,294	6,260	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6880 with 15 sacks cmt on top. CIBP #2: Depth 80 with 25 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 6880 ft. to 6480 ft. Plug Type: CASING Plug Tagged: ☐
Set 150 sks cmt from 4210 ft. to 3810 ft. Plug Type: OPEN HOLE Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 130 sacks half in. half out surface casing from 840 ft. to 660 ft. Plug Tagged: ☒

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: DOREEN GREEN

Title: REGULATORY ANALYST Date: 5/10/2017 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: McCoy, Diane Date: 6/1/2017

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 11/30/2017

COA Type	Description
	1) Prior to starting plugging operations a bradenhead test shall be performed. If the beginning pressure is greater than 25 psi, or if pressure remains at the conclusion of the test, or if any liquids were present contact COGCC Engineer for sampling requirements. The Form 17 shall be submitted within 10 days of the test. 2) Provide 48 hour notice of plugging MIRU via electronic Form 42. 3) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete. 4) Submit gyro survey data with Form 6 Subsequent Report of Abandonment. 5) Leave at least 100' of cement in the wellbore for each plug.

Attachment Check List

Att Doc Num	Name
401279468	FORM 6 INTENT SUBMITTED
401279473	PROPOSED PLUGGING PROCEDURE
401279475	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group	Comment	Comment Date
Engineer	Changed depth of surface casing shoe plug from 815-660' to 840-660' due to a water well within one mile that is 790' deep. Stub plugs are required to have cement half-in (50' below, inside the casing) and half-out (50' above) the casing stub. In this case, due to 3.5 inch casing and the intention to use the production casing as the workstring the production casing stub plug is pumped as an open hole plug above the casing stub.	06/01/2017
Public Room	Document verification complete 05/12/17	05/12/2017

Total: 2 comment(s)