

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401351143

Date Received:

07/26/2017

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 75027

Contact Name: AZUCENA TORRES

Name of Operator: ROSEWOOD RESOURCES INC

Phone: (970) 848-2228

Address: 2101 CEDAR SPRINGS RD STE 1500

Fax: (970) 848-2245

City: DALLAS State: TX Zip: 75201

Email: AZUCENATORRES@ROSEWD.COM

For "Intent" 24 hour notice required,

Name: Welsh, Brian

Tel: (719) 325-6919

COGCC contact:

Email: brian.welsh@state.co.us

API Number 05-125-10779-00

Well Name: SHIVELY

Well Number: 13-35

Location: QtrQtr: NWSW Section: 35 Township: 5S Range: 43W Meridian: 6

County: YUMA

Federal, Indian or State Lease Number:

Field Name: BONNY

Field Number: 7325

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.579677

Longitude: -102.154740

GPS Data:

Date of Measurement: 12/20/2010

PDOP Reading: 2.2

GPS Instrument Operator's Name: Jeremy Roelfs

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	1528	1558			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+1/2	7	17	372	102	372	0	CALC
1ST	6+1/4	4+1/2	10.5	1,727	60	1,727	850	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1478 with 2 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 422 ft. with 80 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
of \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

INTENT TO ABANDON: FILL 4 1/2" CASING AND 7" SURFACE CASING FROM 422' TO SURFACE. CUT OFF CASING 5' BELOW GROUND LEVEL, WELD PLATE AND BACKFILL.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: AZUCENA TORRES

Title: HSE & REGULATORY REP Date: 7/26/2017 Email: AZUCENATORRES@ROSEWD.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 8/10/2017

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_ Expiration Date: 2/9/2018

**COA Type** **Description**

COA Type	Description

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401351143	FORM 6 INTENT SUBMITTED
401354039	WELLBORE DIAGRAM
401354125	WELLBORE DIAGRAM

Total Attach: 3 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Agency	Bradenhead: Prior to initiation of plugging operations, a Bradenhead test shall be performed. Form 17 shall be submitted within 10 days. If there is 25 psi or greater pressure on the Bradenhead, or flowed any liquids from the Bradenhead, collect samples. See COGCC website - Operator Guidance - Bradenhead Testing and Reporting Instructions, Appendix A: Liquid and Gas Sampling.	08/10/2017
Agency	1) Provide 48 hour notice of MIRU via electronic Form 42. 2) Shoe plug: Tag plug 50' above surface casing shoe, if not circulated to surface. 3) Surface plug: Cement from 50' to surface in casing and annulus. 4) Properly abandon flowlines per Rule 1103. File Form 42 when done. 5) Abandoned well marker shall be inscribed with the well's legal location, well name and number, and API Number (Rule 319.a.(5)).	08/10/2017
Public Room	Document verification complete 07/28/17	07/28/2017
Permit	WBDs are for incorrect well. Returned to draft.	07/25/2017

Total: 4 comment(s)