

FORM

6

Rev  
02/20

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

402455533

Date Received:

08/10/2020

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10633

Contact Name: Cole Carveth

Name of Operator: CRESTONE PEAK RESOURCES OPERATING LLC

Phone: (303) 774-3979

Address: 1801 CALIFORNIA STREET #2500

Fax:

City: DENVER State: CO Zip: 80202

Email: cole.carveth@crestonepr.com

For "Intent" 24 hour notice required,

Name: Sherman, Susan

Tel: (719) 775-1111

COGCC contact:

Email: susan.sherman@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-005-06203-00

Well Name: AMOCO-WESTAN-

Well Number: 1

Location: QtrQtr: NENE Section: 8 Township: 4S Range: 64W Meridian: 6

County: ARAPAHOE

Federal, Indian or State Lease Number:

Field Name: WILDCAT

Field Number: 99999

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.722964 Longitude: -104.567020

GPS Data: GPS Quality Value: Type of GPS Quality Value: Date of Measurement:

GPS Instrument Operator's Name:

Reason for Abandonment: ☐ Dry ☐ Production Sub-economic ☐ Mechanical Problems☒ Other Re-plug well to provide proper isolation for offset mitigation for theCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	214	230	214	0	VISU

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set	150	sks cmt from	7400	ft. to	6900	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input type="checkbox"/>
Set	125	sks cmt from	3200	ft. to	3000	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input type="checkbox"/>
Set	290	sks cmt from	1980	ft. to	1400	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	400	sks cmt from	1400	ft. to	700	ft.	Plug Type:	OPEN HOLE	Plug Tagged:	<input checked="" type="checkbox"/>
Set	_____	sks cmt from	_____	ft. to	_____	ft.	Plug Type:	_____	Plug Tagged:	<input type="checkbox"/>

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 350 sacks half in. half out surface casing from 700 ft. to 0 ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Cut and Cap Date: \_\_\_\_\_  
of \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

Proposed plugging procedure is attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jane Washburn

Title: Sr Prod Engineering Tech Date: 8/10/2020 Email: jane.washburn@crestonepr.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Jacobson, Eric Date: 8/11/2020

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 2/10/2021

<b>COA Type</b>	<b>Description</b>
	Moved openhole plug at 1900' down to 1980' Operator to adjust cement accordingly. Operator concurs.
	1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) Prior to placing the 700' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders. 3) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 164' or shallower and provide 10 sack plug at surface. 4) Leave at least 100' of cement in the wellbore for each plug. 5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 6) After placing the shallowest hydrocarbon isolating plug (7400'), operator must wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC engineering before continuing operations.
	Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.

### **Attachment Check List**

<b>Att Doc Num</b>	<b>Name</b>
402455533	FORM 6 INTENT SUBMITTED
402455683	PROPOSED PLUGGING PROCEDURE
402455684	WELLBORE DIAGRAM
402455685	WELLBORE DIAGRAM
402456745	SURFACE OWNER CONSENT
402456747	LOCATION PHOTO

Total Attach: 6 Files

### **General Comments**

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>
Engineer	Well file verification not completed prior to approval of NOIA.	08/11/2020
Engineer	Deepest Water Well within 1 Mile – 1930' SB5 Base of Fox Hills - 1813'	08/11/2020
Permit	Well was DA in 1971, SHL unverifiable with satellite and aerial photo imagery. Location checks @ 660' FNL & 670' FEL of Sec. 8 on COGCC GIS. No perferd intervals to verify. No production records to verify.	08/11/2020
Engineer	Denver 4924 5391 222.3 667 200 60.47 NNT Upper Arapahoe 4628 4860 134.3 963 731 36.53 NT Lower Arapahoe 4319 4553 65.1 1272 1038 17.71 NT Laramie-Fox Hils 3778 4010 155.6 1813 1581 37.34 NT	08/10/2020

Total: 4 comment(s)