

Document Number:
402552417

Date Received:
12/11/2020

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: JEnifer Hakkarinen
 Name of Operator: PDC ENERGY INC Phone: (303) 8605800
 Address: 1775 SHERMAN STREET - STE 3000 Fax: _____
 City: DENVER State: CO Zip: 80203 Email: JEnifer.Hakkarinen@pdce.com

For "Intent" 24 hour notice required, Name: Peterson, Tom Tel: (970) 370-1281
COGCC contact: Email: tom.peterson@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-123-20276-00 Well Number: 23-29
 Well Name: OLSON
 Location: QtrQtr: NESW Section: 29 Township: 4N Range: 67W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.282310 Longitude: -104.916360
 GPS Data: GPS Quality Value: 1.2 Type of GPS Quality Value: PDOP Date of Measurement: 07/15/2010

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 2500
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7339	7349			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J-55	24	0	400	285	400	0	VISU
1ST	7+7/8	4+1/2	J-55	10.5	0	7523	160	7523	6520	CBL

Subsurface hazards include, but are not limited to, the following: overpressured zones, underpressured zones, major geologic faults, salt sections, H2S at concentrations greater than or equal to 100 ppm.

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7289 with 2 sacks cmt on top. CIBP #2: Depth 6976 with 2 sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 2550 ft. to 2300 ft. Plug Type: STUB PLUG Plug Tagged:
 Set 100 sks cmt from 1430 ft. to 1230 ft. Plug Type: OPEN HOLE Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set 219 sacks half in. half out surface casing from 600 ft. to 0 ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 Surface Plug Setting Date: _____ Cut and Cap Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

Olson 23-29 (05-123-20276)/Plugging Procedure (Intent)
 Producing Formation: Codell: 7339'-7349'
 Upper Pierre Aquifer: 470'-1330'
 TD: 7547' PBSD: 7506' (1/14/2002)
 Surface Casing: 8 5/8" 24# @ 400' w/ 285 sxs cmt
 Production Casing: 4 1/2" 10.5# @ 7523' w/ 160 sxs cmt (TOC @ 6520' - CBL)
 Tubing: 2 3/8" tubing set @ 7329' (1/15/2002)
 Proposed Procedure:
 1. MIRU. Pull 2 3/8" tubing.
 2. RU wireline company.
 3. TIH with CIBP. Set BP at 7289'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Codell perms @ 7339')
 4. TIH with CIBP. Set BP at 6976'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Niobrara @ 7026')
 5. TIH with casing cutter. Cut 4.5" casing at 2500'. Pull cut casing.
 6. TIH with tubing to 2550'. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing. (Courtesy plug from 2550'-2300')
 7. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations
 8. Pick up tubing to 1430'. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing. (Pierre coverage from 1430'-1230').
 9. Pick up tubing to 600'. Mix and pump 219 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
 10. Cut surface casing 6' below ground level and weld on cap.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: JEnifer Hakkarinen

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE

Date: 12/23/2020

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 6/22/2021

COA Type**Description**

	<p>For Wells with known Bradenhead pressures:</p> <ol style="list-style-type: none"> 1) Provide 48-hour notice of plugging MIRU via electronic Form 42. 2) The plug at 1430' needs to be placed and have an 8-hour WOC to assure that all fluid migration has been stopped. If that doesn't isolate the flow, additional attempts in front of the surface shoe plug will need to be attempted. Other downhole potential squeeze opportunities may need to be looked at before the 600' plug. 3) Prior to placing the 600' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders. 4) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 350' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the casing for each plug. 5) Properly abandon flowlines as per Rule 1105. File electronic Form 42 once abandonment is complete. Within 90 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line, the operator must submit a Flowline Report, Form 44. 6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 7) After placing the shallowest hydrocarbon isolating plug (1430'), operator must wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact COGCC engineering before continuing operations.
	Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.
	<p>Prior to starting plugging operations a Bradenhead test shall be performed if there has not been a reported Bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <ol style="list-style-type: none"> 1) If, before opening the Bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p>

Attachment List

Att Doc Num	Name
402552417	FORM 6 INTENT SUBMITTED
402552420	WELLBORE DIAGRAM
402552421	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	1) Deepest Water Well within 1 mile = 590'. 2) Fox Hills Bottom- N/A, per SB5.	12/23/2020
Engineer	In accordance with the Notice to Operators (NTO): Timing for COGCC Forms adopted on 05/01/2020, this Form 6 Notice of Intent to Abandon is valid for 12 months from the date of approval expiring on 12/23/2021. This NTO does not alter the deadlines for submission of, or compliance with any other Commission rule or Form.	12/23/2020
Permit	Verified as-drilled GPS. Verified perf zone. Verified production reporting. Permitting review complete.	12/17/2020

Total: 3 comment(s)