

FORM
6Rev
11/20

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

402785382

Date Received:

08/19/2021

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10699	Contact Name: Pat Dolezal
Name of Operator: OWN RESOURCES OPERATING LLC	Phone: (970) 332-3585
Address: 38 PALMER CREST CT	Fax:
City: SPRING State: TX Zip: 77381	Email: pat.dolezal@ownresources.com
For "Intent" 24 hour notice required, Name: Sherman, Susan Tel: (719) 775-1111 COGCC contact: Email: susan.sherman@state.co.us	

 Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number: 05-125-11785-00	Well Number: 31-09
Well Name: DETERDING	
Location: QtrQtr: NESE Section: 31 Township: 1N Range: 44W Meridian: 6	
County: YUMA	Federal, Indian or State Lease Number:
Field Name: VERNON	Field Number: 86500

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.007552	Longitude: -102.325787
GPS Data: GPS Quality Value: 1.8	Type of GPS Quality Value: PDOP
Date of Measurement: 07/25/2010	
Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems	
<input checked="" type="checkbox"/> Other WO	
Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	Estimated Depth:
Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input type="checkbox"/> No	If yes, explain details below
Details:	

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	9+7/8	7	j-55	17	0	395	95	395	0	VISU
1ST	6+1/4	4+1/2	j-55	11.6	0	2624	90	2624	1624	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2236 with 2 sacks cmt on top. CIBP #2: Depth 1674 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 465 ft. with 110 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____

*Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Pat Dolezal

Title: Regulatory Specialist Date: 8/19/2021 Email: pat.dolezal@ownresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 10/13/2021

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 4/12/2022

Condition of Approval

COA Type

Description

	<p>Bradenhead Testing</p> <p>Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <p>1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.</p> <p>2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p>
	<p>Plugging</p> <p>1) Provide 48 hour notice of plugging MIRU via electronic Form 42.</p> <p>2) Contact COGCC Area Inspector prior to commencing plugging operations.</p> <p>3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained.</p> <p>4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Tag at tops specified or shallower. Notify COGCC Area Engineer before adding cement to previous plug.</p> <p>5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap.</p> <p>6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.</p> <p>7) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations.</p> <p>8) After placing the shallowest hydrocarbon isolating plug (2236'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC Area Engineer before continuing operations.</p> <p>9) Verify existing cement coverage by CBL - submit to COGCC Area Engineer for verification of plugging orders prior to continuing plugging operations</p> <p>10) Move CIBP w/ 2 sx to 1674' or 50' below top of cement as seen on the CBL.</p> <p>11) Increase shoe/surface plug to 465-0', adjust cement volume accordingly. Intent of this plug is to circulate cement to surface. Tag at 345' or shallower. Contact COGCC Area Engineer before adding cement to this plug.</p> <p>12) Submit corrected WBD prior to filing Form 42 Notification required in #1 above.</p>
	<p>Operator will implement measures to capture, combust, or control emissions to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public health, welfare and the environment.</p>

3 COAs

Attachment List

Att Doc Num

Name

402785382	FORM 6 INTENT SUBMITTED
402785385	WELLBORE DIAGRAM
402785386	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Groundwater: High Plains Aquifer Deepest Water Well: 360+3957-3956+50=411' Log: 125-11785 5/23/10 GR 3957'	10/13/2021
Permit	Removed NBRR panel from zones tab as this well was never completed.	08/20/2021

Total: 2 comment(s)