



00283938

CONSERVATION COMMISSION
NT OF NATURAL RESOURCES
STATE OF COLORADO

File in duplicate for Patented and Federal lands.
File in triplicate for State lands.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO.	
2. NAME OF OPERATOR Petroleum, Inc.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 60, Casper, WY 82602-0060		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface SE SW Sec. 22-T12N-R56W, 1980' FWL, 660' FSL At proposed prod. zone		8. FARM OR LEASE NAME Buczkwskyj	
14. PERMIT NO.		9. WELL NO. #7	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4923 GL		10. FIELD AND POOL, OR WILDCAT Sleeper	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 22-T12N-R56W	
		12. COUNTY Weld	13. STATE Colorado

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Date of work May, 1986

Casing, 6409 ft. 5½" O.D.

294 ft. 8-5/8" O.D.

Tubing, 6320 ft. 2-7/8" O.D., 6.5# per foot, J-55, EUE

Perforations, "J" Sand, 6320 to 6328 ft, 2 SPF

Petroleum, Inc. intends to plug and abandon the well as follows:

- 1) Set a cast iron bridge plug at 6250' KBM. Place 5 sx cement on bridge plug.
- 2) Fill the casing with drilling mud.
- 3) Shoot off the casing at 650' KBM, and pull the casing.
- 4) Place a 150 ft. cement plug from 600' to 450', 50 sx.
- 5) Place a 30 ft. cement plug at bottom of surface, 280' to 310', 30 sx.
- 6) Place 20 sx at surface.
- 7) Weld a steel plate over the surface casing and reclaim as the rancher requires.

18. I hereby certify that the foregoing is true and correct

SIGNED

Daniel Bulfer

TITLE District SuperintendentDATE 3/21/86

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

Aug. P. E.

DATE

MAR 24 1986