



FOR OGCC USE ONLY

Date Received: 6/20/2006

01805246

WELL ABANDONMENT REPORT

Submit original plus one copy. This form is to be submitted as an intent whenever a plugging is planned on a borehole. The approved intent shall be valid for six (6) months after the approval date; after that period a new intent will be required. After the plugging is complete, this form and one copy shall again be submitted along with third party cement verification as a subsequent report of the work as actually completed.

OGCC Operator Number: 6575	Contact Name and Telephone EDDIE BATES	24-hour Contact (required) JIM PRECUP
Name of Operator: BATES* JAMES EDWARD	Phone: 303 521-3959	Tel: 303 469-1902
Address: P O BOX 796	Fax:	
City: BRIGHTON State: CO Zip: 80601		

API Number: 05-001-08475 00	OGCC Lease No.:	Other wells in this lease?
Well Name: GUTHRIE	Well Number: 2-8	
Location (QtrQtr, Sec, Twp, Rng, Mer):	SENW Sec 2 T 1S R 67W PM 6	
County: ADAMS	Federal, Indian, or State Lease Number:	
Field Name: SPINDLE	Field Number: 77900	

Attachment Checklist	Doc Num

Notice of Intent to Abandon

Only Complete the Following Background Information for Intent to Abandon

Reason for Abandonment: PRODUCTION

Casing to Be Puled: No **Top of Casing Cement:**

Fish in Hole: No

Wellbore has Uncemented Casing Leaks: No

Details: HOUSING DEVELOPMENT

Current and Previously Abandoned Zones

Formation code	Perf Top	Perf Bottom	Date Abandoned	Method of Isolation	Plug Depth
SUSX	4900	4975			

Casing History

Casing String	Casing Size	Casing Depth	Cement Top	Cement Bottom
SURF	8 5/8	221		
STAGE TOOL	/	1052	686	
1ST	4 1/2	5080		

Plugging Procedure for Intent and Subsequent Report

CIBP # 1: Depth 4850 ft. with 2 sacks cement on top. NOTE: Two(2) sacks cement required on all CIBPs.

CIBP # 2: Depth 1030 ft. with 2 sacks cement on top.

Perforate and squeeze at 350 ft. with 125 sacks. Leave at least 100 ft. in casing. → *circulate cement to surface (see COA below)*

Cut all casing strings four feet below ground level, weld on plate Dry-Hide Marker :

Set sacks in rat hole. Set sacks in mouse hole.

Additional Plugging Information for Subsequent Report Only

Casing Recovered: ft. of inch casing. **Plugging Date:**

***Wireline Contractor:** ***Cementing Contractor:**

Type of Cement and Additives Used: ***Attach Job Summaries**

I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct, and complete.

Print Name: EDDIE BATES VERBAL

Signed? No

Title: OWNER

Date: 6/20/2006

OGCC Approved: ROBBINSL *RR*

Title: Eng

Date: 6/20/2006

CONDITIONS OF APPROVAL, IF ANY:

SET CIBP AT 1030' AND DUMP BAIL 2 SX CEMENT. PRESSURE CASING TO 300 PSI FOR 15 MINUTES TO VERIFY INTEGRITY. PERFORATE CASING AT 350' AND CIRCULATE CEMENT TO SURFACE. CONTACT JIM PRECUP 48 HOURS PRIOR TO STARTING PLUGGING AND ABANDONMENT WORK AT 303-469-1902.