

<div>FORM</div> <div>6</div> <div>Rev 11/20</div>	<div>State of Colorado</div> <div>Energy &amp; Carbon Management Commission</div> <div>1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109</div>		<div><div><div></div></div><div><div></div></div></div>		<div>DE</div> <div>ET</div> <div>OE</div> <div>ES</div>																																	
	<div>Document Number:</div> <div>403850790</div> <div>Date Received:</div> <div>07/11/2024</div>																																					
<div>WELL ABANDONMENT REPORT</div> <div><div><div>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</div></div></div>																																						
<div>ECMC Operator Number: 10699</div> <div>Name of Operator: OWN RESOURCES OPERATING LLC</div> <div>Address: 305 S RIDGE STREET #6279</div> <div>City: BRECKENRIDGE State: CO Zip: 80424</div>			<div>Contact Name: James Krehmeyer</div> <div>Phone: (970) 332-3585</div> <div>Fax:</div> <div>Email: james.krehmeyer@ownresources.com</div>																																			
<div>For "Intent" 24 hour notice required,</div> <div>ECMC contact:</div>			<div>Name: Welsh, Brian</div> <div>Email: brian.welsh@state.co.us</div> <div>Tel: (719) 325-6919</div>																																			
<div>Type of Well Abandonment Report: <input checked="" type="checkbox"/> Notice of Intent to Abandon <input type="checkbox"/> Subsequent Report of Abandonment</div>																																						
<div>API Number 05-125-06613-00</div> <div>Well Name: CANTRALL Well Number: 1-35</div> <div>Location: QtrQtr: NENW Section: 35 Township: 1S Range: 45W Meridian: 6</div> <div>County: YUMA Federal, Indian or State Lease Number:</div> <div>Field Name: DUKE Field Number: 18890</div>																																						
<div>Only Complete the Following Background Information for Intent to Abandon</div> <div>Latitude: 39.931420 Longitude: -102.385305</div> <div>GPS Data: GPS Quality Value: 5.4 Type of GPS Quality Value: PDOP Date of Measurement: 05/16/2007</div> <div>Reason for Abandonment: <input type="checkbox"/> Dry <input checked="" type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems</div> <div><input type="checkbox"/> Other</div> <div>Casing to be pulled: <input type="checkbox"/> Yes <input type="checkbox"/> No Estimated Depth:</div> <div>Fish in Hole: <input type="checkbox"/> Yes <input type="checkbox"/> No If yes, explain details below</div> <div>Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input type="checkbox"/> No If yes, explain details below</div> <div>Details:</div>																																						
<div>Current and Previously Abandoned Zones</div> <table><tr><th>Formation</th><th>Perf. Top</th><th>Perf. Btm</th><th>Abandoned Date</th><th>Method of Isolation</th><th>Plug Depth</th></tr><tr><td>NIOBRARA</td><td>2246</td><td>2260</td><td></td><td></td><td></td></tr></table> <div>Total: 1 zone(s)</div>						Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth	NIOBRARA	2246	2260																								
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																																	
NIOBRARA	2246	2260																																				
<div>Casing History</div> <table><tr><th>Casing Type</th><th>Size of Hole</th><th>Size of Casing</th><th>Grade</th><th>Wt/Ft</th><th>Csg/Liner Top</th><th>Setting Depth</th><th>Sacks Cmt</th><th>Cmt Btm</th><th>Cmt Top</th><th>Status</th></tr><tr><td>SURF</td><td>9+7/8</td><td>7</td><td>j-55</td><td>17</td><td>0</td><td>280</td><td>60</td><td>280</td><td>0</td><td>VISU</td></tr><tr><td>1ST</td><td>6+1/8</td><td>4+1/2</td><td>j-55</td><td>9.5</td><td>0</td><td>2560</td><td>100</td><td>2560</td><td>1260</td><td>CALC</td></tr></table>						Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	9+7/8	7	j-55	17	0	280	60	280	0	VISU	1ST	6+1/8	4+1/2	j-55	9.5	0	2560	100	2560	1260	CALC
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																												
SURF	9+7/8	7	j-55	17	0	280	60	280	0	VISU																												
1ST	6+1/8	4+1/2	j-55	9.5	0	2560	100	2560	1260	CALC																												

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2196 with 2 sacks cmt on top. CIBP #2: Depth 1415 with 2 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 330 ft. with 100 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing

Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_ Number of Days from Setting Surface Plug to Capping or Sealing the Well: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_

\*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Pat Dolezal

Title: Regulatory Specialist Date: 7/11/2024 Email: pat.dolezal@ownresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: Wolfe, Stephen

Date: 7/29/2024

### CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: 1/28/2025

COA Type	Description
	<p>Bradenhead Testing</p> <p>Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <p>1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.</p> <p>2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the ECMC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact ECMC engineering for verification of plugging procedure.</p>
	<p>Consistent with Rule 911.a, a Form 27 must be approved prior to cut and cap, conducting flowline abandonment, or removing production equipment. Allow 30 days for Director review of the Form 27; include the Form 27 document number on the Form 44 for offsite flowline abandonment (if applicable) and on the Form 6 Subsequent.</p>
	<p>Properly abandon flowlines per Rule 1105. If flowlines will be abandoned in place, include with the Form 27: pressure test results conducted in the prior 12 months as well as identification of any document numbers for a ECMC Spill/Release Report, Form 19, associated with the abandoned line.</p>
	<p>Plugging</p> <p>1) Provide electronic Form 42 Notice of MIRU 2 business days ahead of operations and electronic Form 42 Notice of Plugging Operations 48 hours prior to mobilizing for plugging operations.</p> <p>2) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from ECMC is obtained.</p> <p>3) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Wait on cement(WOC) a minimum of 4 hrs before tagging a plug. Tag at tops specified or shallower. Notify ECMC Area Engineer before adding cement to previous plug due to low cement top.</p> <p>4) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface and complete isolation in all strings during cut and cap. After cut and prior to cap, verify isolation by either a 15 minute bubble test or 15 minute optical gas imaging recording. If there is indication of flow contact ECMC Engineering. Provide a statement on the 6 SRA which method was used and what was observed. Retain records of final isolation test for 5 years.</p> <p>5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.</p> <p>6) Operator must wait a sufficient time on all plugs to achieve the intended design. If at any time during the plugging there is evidence of previously unreported pressure or fluid migration, contact ECMC Area Engineer before continuing operations.</p> <p>7) Plugging procedure has been modified as follows,        Plug #1 - 2196', CIBP with 2 sx of cement,        Run a CBL to confirm TOC before pumping Plug #2, adjust depth to 50' below the TOC,        Plug #2 - 1415', CIBP with 2 sx of cement on top of CIBP,        Plug #3 - 330', perf and circulate 100 sx to surface, If perms will take fluid but do not circulate or circulation is lost, pump a minimum of 50 sx and displace to 180', 100' above the surface shoe. WOC and tag at 230' or shallower. Notify ECMC Area Engineer of insufficient cement prior to pumping additional plugs,        Plug #4 - 50' of cement at the surface in both the casing and the annulus per COA #4.</p> <p>8) Submit any logs run during the plugging with the Form 6 SRA.</p>

	Due to close proximity to Residential Building Units (RBUs), prior to commencing operations, at a minimum, the operator will provide an informational sheet to the owners/occupants of the RBUs nearby and adjacent to the parcel with the well. The sheet will include the operator's contact information and the nature, timing, and expected duration of the P&A operations. Operator will implement measures to capture, combust, or control emissions to protect health and safety, and to ensure that vapors, odors and noise from plugging operations do not constitute a nuisance or hazard to public health, welfare and the environment.
5 COAs	

**ATTACHMENT LIST**

<b><u>Att Doc Num</u></b>	<b><u>Name</u></b>
403850790	FORM 6 INTENT SUBMITTED
403851962	PROPOSED PLUGGING PROCEDURE
403851963	WELLBORE DIAGRAM

Total Attach: 3 Files

**General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
Engineer	Aquifer- High Plains Deepest water well- 217'(1mi, 18 records) Log- 125-06828 8/3/82	07/29/2024
OGLA	Location Assessment Specialist (LAS) review complete. Well is not in a HPH and not near surface waters or wetlands.	07/22/2024
Permit	Wellbore diagrams do not match (see perms). Confirm perf interval on zones tab. Returned to draft.	07/11/2024

Total: 3 comment(s)