

**FORM**  
**6**  
Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**



|    |    |    |    |
|----|----|----|----|
| DE | ET | OE | ES |
|----|----|----|----|

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109

Date Received:

Document Number:

400172169

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100185 Contact Name: Marina Ayala  
 Name of Operator: ENCANA OIL & GAS (USA) INC Phone: (720) 876-5905  
 Address: 370 17TH ST STE 1700 Fax: (720) 876-4905  
 City: DENVER State: CO Zip: 80202- Email: marina.ayala@encana.com

**24 hour notice required, contact:** Name: LONGWORTH, MIKE Tel: (970) 812-7644  
 Email: mike.longworth@state.co.us

API Number 05-103-08628-00 Well Number: 1058  
 Well Name: DRAGON TRAIL UNIT  
 Location: QtrQtr: SESE Section: 29 Township: 2S Range: 102W Meridian: 6  
 County: RIO BLANCO Federal, Indian or State Lease Number: COC02864  
 Field Name: DRAGON TRAIL Field Number: 18700

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.841581 Longitude: -108.861571  
 GPS Data:  
 Data of Measurement: 01/23/2007 PDOP Reading: 1.5 GPS Instrument Operator's Name: GREG OSLEN  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Top of Casing Cement: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

| Formation | Code   | Perf. Top | Perf. Bottom | Date | Method of Isolation | Plug Depth |
|-----------|--------|-----------|--------------|------|---------------------|------------|
| MANCOS A  | MNCS A | 3082      | 3138         |      |                     |            |
| MANCOS B  | MNCS B | 3317      | 3667         |      |                     |            |

Total: 2 zone(s)

**Casing History**

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF        | 12+1/4       | 8+5/8          | 24              | 230           | 150          | 230        | 0          | CALC   |
| 1ST         | 7+7/8        | 5+1/2          | 15.5            | 3,863         | 105          | 3,863      | 0          | CBL    |
|             |              |                | Stage Tool      | 2,518         | 200          | 2,518      | 1,678      |        |

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 3022 with 6 sacks cmt on top. CIPB #2: Depth 300 with 36 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 290 ft. with 50 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Provide Technical Detail:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Marina Ayala  
 Title: Permitting Technician Date: \_\_\_\_\_ Email: marina.ayala@encana.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

### Attachment Check List

| Att Doc Num | Name                        |
|-------------|-----------------------------|
| 400172214   | PROPOSED PLUGGING PROCEDURE |
| 400172215   | WELLBORE DIAGRAM            |
| 400172217   | WELLBORE DIAGRAM            |

Total Attach: 3 Files

**General Comments**

| <b><u>User Group</u></b> | <b><u>Comment</u></b> | <b><u>Comment Date</u></b> |
|--------------------------|-----------------------|----------------------------|
|                          |                       |                            |

Total: 0 comment(s)