

**FORM**  
**6**  
Rev  
12/05

State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Date Received:  
06/13/2011

Document Number:  
1771324

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 46290 Contact Name: Kent Gilbert  
Name of Operator: K P KAUFFMAN COMPANY INC Phone: (303) 825-4822  
Address: 1675 BROADWAY, STE 2800 Fax: (303) 825-4825  
City: DENVER State: CO Zip: 80202 Email: kgilbert@kpk.com

**For "Intent" 24 hour notice required, COGCC contact:** Name: PRECUP, JIM Tel: (303) 726-3822  
Email: james.precup@state.co.us

API Number 05-123-07593-00  
Well Name: CHAMPLIN 86 AMOCO B Well Number: 1  
Location: QtrQtr: SWNE Section: 33 Township: 2N Range: 68W Meridian: 6  
County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
Field Name: SPINDLE Field Number: 77900

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.096860 Longitude: -105.006150  
GPS Data:  
Data of Measurement: 08/13/2007 PDOP Reading: 1.6 GPS Instrument Operator's Name: R. Gorka  
Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other well sold to surface developer  
Casing to be pulled:  Yes  No Top of Casing Cement: \_\_\_\_\_  
Fish in Hole:  Yes  No If yes, explain details below  
Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
Details: will run CBL to determine TOC

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SHANNON	5044	5062			
SUSSEX	4590	4635			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	9+5/8	32.5	228	300	228	0	
1ST	8+3/4	7	20,23	5,149	250	5,149	4,149	CALC
			Stage Tool	942	200	942	50	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4540 with 3 sacks cmt on top. CIPB #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 990 ft. to 790 ft. in Plug Type: CASING Plug Tagged:   
 Set 50 sks cmt from 280 ft. to 50 ft. in Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set 10 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Rick Ramos  
 Title: Supervisor Date: 6/9/2011 Email: rteter@kpk.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURN, DIANA Date: 6/13/2011

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 12/12/2011

1) Provide 24 hour notice of MIRU to Jim Precup at 303-469-1902 or e-mail at James.Precup@state.co.us. 2) The CBL run prior to the plugging must indicate the presence of good cement from the DV tool at 942' into the surface shoe with a minimum TOC of 50'. Both the 990' and the 280'shoe plugs should be tagged. 3) If cement not found as expected then contact COGCC for a modification of plugging procedures. 4) Properly abandon flowlines as per Rule 1103. 5) This well was on the Bradenhead testing list from December 2009 and there is no Bradenhead test form on file for this well - please submit the Bradenhead Test Form.

### Attachment Check List

Att Doc Num	Name
1771324	FORM 6 INTENT SUBMITTED

Total Attach: 1 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)