

<b>FORM</b> <b>6</b> Rev 12/05	<b>State of Colorado</b> <b>Oil and Gas Conservation Commission</b> 1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109		DE ET OE ES
			Date Received:  06/07/2011  Document Number:  400172169

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>100185</u>	Contact Name: <u>Marina Ayala</u>
Name of Operator: <u>ENCANA OIL &amp; GAS (USA) INC</u>	Phone: <u>(720) 876-5905</u>
Address: <u>370 17TH ST STE 1700</u>	Fax: <u>(720) 876-4905</u>
City: <u>DENVER</u> State: <u>CO</u> Zip: <u>80202-56</u>	Email: <u>marina.ayala@encana.com</u>
<b>For "Intent" 24 hour notice required, COGCC contact:</b>	
Name: <u>LONGWORTH, MIKE</u>	Tel: <u>(970) 812-7644</u>
Email: <u>mike.longworth@state.co.us</u>	

API Number <u>05-103-08628-00</u>	Well Name: <u>DRAGON TRAIL UNIT</u>	Well Number: <u>1058</u>
Location: QtrQtr: <u>SESE</u> Section: <u>29</u> Township: <u>2S</u> Range: <u>102W</u> Meridian: <u>6</u>	County: <u>RIO BLANCO</u> Federal, Indian or State Lease Number: <u>COC02864</u>	
Field Name: <u>DRAGON TRAIL</u>	Field Number: <u>18700</u>	

**Notice of Intent to Abandon**
                         
  **Subsequent Report of Abandonment**

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: <u>39.841581</u>	Longitude: <u>-108.861571</u>
GPS Data:	
Data of Measurement: <u>01/23/2007</u>	PDOP Reading: <u>1.5</u> GPS Instrument Operator's Name: <u>GREG OSLEN</u>
Reason for Abandonment: <input type="checkbox"/> Dry <input checked="" type="checkbox"/> Production for Sub-economic <input type="checkbox"/> Mechanical Problems	
<input type="checkbox"/> Other _____	
Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	Top of Casing Cement: _____
Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input type="checkbox"/> No	If yes, explain details below
Details: _____	

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
MANCOS A	3082	3138			
MANCOS B	3317	3667			
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	230	150	230	0	VISU
1ST	7+7/8	5+1/2	15.5	3,863	105	3,863	2,695	CBL
			Stage Tool	2,518	200	2,518	1,678	CBL

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 3022 with 6 sacks cmt on top. CIPB #2: Depth 300 with 36 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 290 ft. with 50 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 (Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

#### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:  
 \_\_\_\_\_

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Marina Ayala  
 Title: Permitting Technician Date: 6/7/2011 Email: marina.ayala@encana.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: KRABACHER, JAY Date: 7/8/2011

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 1/7/2012

\_\_\_\_\_

**IMPORTANT: SOME DATA FIELDS HAVE BEEN MODIFIED.**

### **Attachment Check List**

<b>Att Doc Num</b>	<b>Name</b>
400172169	FORM 6 INTENT SUBMITTED
400172214	PROPOSED PLUGGING PROCEDURE
400172215	WELLBORE DIAGRAM
400172217	WELLBORE DIAGRAM

Total Attach: 4 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>

Total: 0 comment(s)