

FORM  
6Rev  
12/05State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80205 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

2332364

Date Received:

04/19/2012

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10334

Contact Name: DON SMITH

Name of Operator: SLAWSON EXPLORATION COMPANY INC

Phone: (303) 592-8880

Address: 1675 BROADWAY - SUITE 1600

Fax: (303) 592-8881

City: DENVER State: CO Zip: 80202

Email: DSMITH@SLAWSONCOMPANIES.COM

For "Intent" 24 hour notice required,

Name: MONTOYA, JOHN

Tel: (970) 3974124

COGCC contact:

Email: john.montoya@state.co.us

API Number 05-123-32012-00

Well Name: Whiskey Jack

Well Number: 16-9-63

Location: QtrQtr: SE SE Section: 16 Township: 9N Range: 63W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 8666.5

Field Name: WILDCAT

Field Number: 99999

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.742300

Longitude: -104.431390

GPS Data:

Date of Measurement: 05/26/2010

PDOP Reading: 0.0

GPS Instrument Operator's Name: These are plan not as-

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Top of Casing Cement: \_\_\_\_\_Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details: \_\_\_\_\_

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
CONDUCTOR	24	16	55.5	40		40	0	VISU
SURF	12+1/4	9+5/8	36	1,211	450	1,211	0	VISU

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 265 ft. to 165 ft. Plug Type: CASING Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set 20 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: DON SMITH PE

Title: SPECIAL PROJECT ENGINEER Date: 4/16/2012 Email: DSMITH@SLAWSONCOMPANIES.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HOLLINSHEAD, RYAN Date: 4/24/2012

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 10/23/2012

- 1)Provide 48 hour notice of MIRU to John Montoya at (970) 397-4124.
- 2)Surface cement plug must fill the upper 50 feet of the casing and the upper 50 feet of all open annular spaces between casing strings.
- 3)Operator must provide well location GPS coordinates on Subsequent Report of Abandonment in accordance with COGCC As-Built Location Policy and Rule 215.
- 4)Provide an "As Plugged" wellbore diagram identifying the specific plugging completed.
- 5)Properly abandon any flowlines as per Rule 1103.
- 6)Operator must tag plugs upon verbal request by the COGCC engineer or COGCC field inspector.
- 7)Prior to or in conjunction with the submittal of the Form 6 Subsequent Report of Abandonment, all well production records shall be brought up to date. This includes any periods that the well was shut in or temporary abandoned, as production must be reported from spud to plug even if the well's production is zero.

FINAL WELL LOCATION GPS COORDINATES (AS-DRILLED) MUST BE SUBMITTED WITH THE SUBSEQUENT FORM 6.

### **Attachment Check List**

Att Doc Num	Name

Total Attach: 0 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>
Engineer	No new water wells have been drilled within the two mile radius. Therefore, the existing surface casing check on file is still valid and the surface casing depth is adequate.	4/24/2012 2:35:13 PM
Permit	WELLBORE DIAGRAMS ATTACHED TO FORM 6 INTENT SUBMITTED.	4/23/2012 9:26:22 AM

Total: 2 comment(s)