

FORM  
6

Rev  
12/05

State of Colorado  
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400301779

Date Received:

07/06/2012

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 49100 Contact Name: Natalie Naeve  
 Name of Operator: KOCH EXPLORATION COMPANY, LLC Phone: (303) 325-2565  
 Address: 950 17TH STREET #1900 Fax: (303) 325-2599  
 City: DENVER State: CO Zip: 80202 Email: natalie.naeve@kochind.com

**For "Intent" 24 hour notice required,** Name: NEIDEL, KRIS Tel: (970) 819-9609  
**COGCC contact:** Email: kris.neidel@state.co.us

API Number 05-103-09714-00 Well Number: 21-9  
 Well Name: WRD FEDERAL  
 Location: QtrQtr: NESE Section: 21 Township: 2N Range: 97W Meridian: 6  
 County: RIO BLANCO Federal, Indian or State Lease Number: 48095  
 Field Name: WHITE RIVER Field Number: 92800

Notice of Intent to Abandon  Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.126932 Longitude: -108.276257  
 GPS Data:  
 Date of Measurement: 09/08/2010 PDOP Reading: 2.0 GPS Instrument Operator's Name: Roth  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
WASATCH	748	753			
WASATCH A	1162	1168	09/25/1994	B PLUG CEMENT TOP	1121

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
CONDUCTOR	12+3/4	9+5/8	36	52	80	52	0	VISU
SURF	8+3/4	7	23	444	150	444	0	VISU
1ST	6+1/4	4+1/2	10.5	1,474	175	1,474	0	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 12 sks cmt from 825 ft. to 675 ft. Plug Type: CASING Plug Tagged:   
Set 40 sks cmt from 500 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set \_\_\_\_\_ sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

Perforations at 1162-1168' were plugged back via CIBP set at 1121' with 2 sacks cement on top.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Natalie L. Naeve  
Title: Operations Engineer Date: 7/6/2012 Email: natalie.naeve@kochind.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: KRABACHER, JAY Date: 7/16/2012

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 1/15/2013

\_\_\_\_\_

### Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400301779	FORM 6 INTENT SUBMITTED
400301803	WELLBORE DIAGRAM
400301804	WELLBORE DIAGRAM
400301805	PROPOSED PLUGGING PROCEDURE

Total Attach: 4 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	old style comp. rept. #580494 sub. 11/7/1994 & rept. #580493 sub. 11/7/94 meet form 5/5A requirements.	7/9/2012 7:16:37 AM

Total: 1 comment(s)