

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400322144

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 66561

Contact Name: Janna Burton

Name of Operator: OXY USA INC

Phone: (620) 629-4206

Address: PO BOX 27757

Fax: (620) 624-7014

City: HOUSTON State: TX Zip: 77227

Email: janna\_burton@oxy.com

For "Intent" 24 hour notice required,

Name: QUINT, CRAIG

Tel: (719) 767-8939

COGCC contact:

Email: craig.quint@state.co.us

API Number 05-011-06100-00

Well Name: ROWE A

Well Number: 1

Location: QtrQtr: NENE Section: 25 Township: 21S Range: 48W Meridian: 6

County: BENT

Federal, Indian or State Lease Number:

Field Name: MCCLAVE

Field Number: 53600

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 38.198660

Longitude: -102.745196

GPS Data:

Date of Measurement: 03/27/2010

PDOP Reading: 5.0

GPS Instrument Operator's Name: PAT MCDOWELL

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☒ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No

Estimated Depth:

Fish in Hole: ☐ Yes ☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☒ Yes ☐ No

If yes, explain details below

Details: 2 3/8" tbg & 4 1/2" csg have suspected holes at unknown depths. Also, tbg could be collapsed at 3730'.  
Tbg and pkr info: 153 jts 2 3/8" tbg @ 4629' w/ SN @ 4622' & Pengo GS III packer @ 4629'.

## Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
MORROW	MRRW	4684	4690			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	344	300	344	0	VISU
S.C. 1.1	7+7/8	4+1/2	10.5	4,885	175	4,885	3,944	CBL
S.C. 1.2	7+7/8	4+1/2	10.5	1,935	150	1,935	1,000	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 3650 with 2 sacks cmt on top. CIPB #2: Depth 650 with 2 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 600 ft. with 175 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

The following is planned:  
-jet cut the 2 3/8" tbg @ +/- 3700' and reclaim tbg  
-set CIBP @ +/- 3650' w/ 2 sx cmt on top  
-set CIBP @ +/- 650' w/ 2 sx cmt on top  
-perf 4 holes @ 600'  
-hook on to wellhead and circ cmt to surface down 4 1/2" csg and up 4 1/2" X 8 5/8" annulus

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Janna Burton

Title: Regulatory Assistant Date: \_\_\_\_\_ Email: janna\_burton@oxy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

### **Attachment Check List**

Att Doc Num	Name
400323487	WELLBORE DIAGRAM
400323491	WELLBORE DIAGRAM

Total Attach: 2 Files

### **General Comments**

<b><u>User Group</u></b>	<b><u>Comment</u></b>	<b><u>Comment Date</u></b>

Total: 0 comment(s)