

FORM
6Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



| | | | |
|----|----|----|----|
| DE | ET | OE | ES |
|----|----|----|----|

Document Number:

400330900

Date Received:

09/26/2012

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: CHERYL LIGHT

Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP

Phone: (720) 929-6461

Address: P O BOX 173779

Fax: (720) 929-7461

City: DENVER State: CO Zip: 80217-

Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: MONTOYA, JOHN

Tel: (970) 3974124

COGCC contact:

Email: john.montoya@state.co.us

API Number 05-123-19351-00

Well Name: HSR-TANIDA

Well Number: 10-6

Location: QtrQtr: NWSE Section: 6 Township: 4N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number: 63817

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.340740

Longitude: -104.931200

GPS Data:

Date of Measurement: 07/18/2006

PDOP Reading: 2.5

GPS Instrument Operator's Name: Chris Fisher

Reason for Abandonment: ☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 6334

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 7070 | 7076 | | | |
| NIOBRARA | 6757 | 6862 | | | |

Total: 2 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 502 | 350 | 525 | 0 | CALC |
| 1ST | 7+7/8 | 4+1/2 | 11.6 | 7,183 | 140 | 7,208 | 6,334 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6700 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

| | | |
|--|-----------------------------|---------------------------------------|
| Set <u>75</u> sks cmt from <u>6330</u> ft. to <u>6130</u> ft. | Plug Type: <u>STUB PLUG</u> | Plug Tagged: <input type="checkbox"/> |
| Set <u>400</u> sks cmt from <u>4690</u> ft. to <u>3815</u> ft. | Plug Type: <u>OPEN HOLE</u> | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 225 sacks half in. half out surface casing from 610 ft. to 0 ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST Date: 9/26/2012 Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HOLLINSHEAD, RYAN Date: 10/4/2012

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 4/3/2013

- 1) Provide 48 hour notice of MIRU to John Montoya at (970) 397-4124.
- 2) Provide an "As Plugged" wellbore diagram identifying the specific plugging completed.
- 3) Cut and pull casing above the top of cement. Cement plug across casing stub from 6330' to 6130' assumes that the casing is cut off at 6230'. Adjust depths for this plug, as necessary, depending on the actual depth of the casing stub.
- 4) If unable to pull casing contact COGCC for plugging modifications.
- 5) Properly abandon flowlines as per Rule 1103.
- 6) Operator must tag plugs upon verbal request by the COGCC engineer or COGCC field inspector.
- 7) See plugging changes above.

Attachment Check List

| Att Doc Num | Name |
|--------------------|-----------------------------|
| 400330900 | FORM 6 INTENT SUBMITTED |
| 400330903 | PROPOSED PLUGGING PROCEDURE |
| 400330904 | WELLBORE DIAGRAM |
| 400330905 | WELLBORE DIAGRAM |

Total Attach: 4 Files

General Comments

| <u>User Group</u> | <u>Comment</u> | <u>Comment Date</u> |
|--------------------------|-----------------------|----------------------------|
| | | |

Total: 0 comment(s)