



DE ET OE ES

Document Number:
2237769

Date Received:
10/22/2012

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 94300 Contact Name: RANDY WARD
 Name of Operator: WARD & SON* ALFRED Phone: (308) 284-8350
 Address: P O BOX 737 Fax: (308) 284-8351
 City: OGALLALLA State: NE Zip: 69153 Email: RLWARDNE@CHARTER.NET
For "Intent" 24 hour notice required, Name: SCHURE, KYM Tel: (970) 520-3832
COGCC contact: Email: kym.schure@state.co.us

API Number 05-087-07362-00 Well Number: 1
 Well Name: ROBINSON-STATE
 Location: QtrQtr: SWSW Section: 36 Township: 1N Range: 55W Meridian: 6
 County: MORGAN Federal, Indian or State Lease Number: 69/7343-S
 Field Name: STOCKADE Field Number: 79390

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: _____ Longitude: _____
 GPS Data:
 Date of Measurement: _____ PDOP Reading: _____ GPS Instrument Operator's Name: _____
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	4838	4843			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	120	100	120	0	
1ST	7+7/8	4+1/2	10.5	4,756	150	4,956	3,969	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 20 sks cmt from 4830 ft. to 4730 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Perforate and squeeze at 180 ft. with 50 sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
Set 15 sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: RANDY WARD
Title: PRESIDENT Date: 10/19/2012 Email: RLWARDNE@CHARTER.NET

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 10/29/2012

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 4/28/2013

- 1) Provide 24 hour notice of MIRU to Kym Schure at 970-520-3832 or e-mail at Kym.Schure@state.co.us.
- 2) Tag plug at 4830'-4730' or set a CIBP below the cement.
- 3) Tag plug at 180' or use retainer. Establish circulation prior to setting retainer.
- 4) 15 sx at surface means cement from 50' to surface in 4 1/2" casing and in 8 5/8" x 4 1/2" annulus.

Submit "as drilled" GPS data on Subsequent Report of Abandonment. GPS data must meet the requirements of Rule 215.

Attachment Check List

Att Doc Num	Name
2233105	WELLBORE DIAGRAM
2237769	FORM 6 INTENT SUBMITTED
2237770	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Per operator input reason for abandonment and attached wellbore diagram. Operator has submitted a form 1A to become a designated agent.	10/24/2012 12:05:51 PM
Permit	Old style form 5 doc #16119. Requeste current wellbore diagram, reason for well abandonment, operator does not have a designated agent, and informed operator that "as built" GPS is being placed on form as a COA.	10/24/2012 5:50:12 AM

Total: 2 comment(s)