

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:
400436014

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 66571 Contact Name: Ken McKinney
 Name of Operator: OXY USA WTP LP Phone: (970) 985-0384
 Address: P O BOX 27757 Fax: (970) 263-3694
 City: HOUSTON State: TX Zip: 77227 Email: ken_mckinney@oxy.com

For "Intent" 24 hour notice required, Name: LONGWORTH, MIKE Tel: (970) 812-7644
COGCC contact: Email: mike.longworth@state.co.us

API Number 05-045-11167-00 Well Number: 797-24-47D
 Well Name: LOGAN WASH
 Location: QtrQtr: NESE Section: 24 Township: 7S Range: 97W Meridian: 6
 County: GARFIELD Federal, Indian or State Lease Number: _____
 Field Name: GRAND VALLEY Field Number: 31290

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.430640 Longitude: -108.161280
 GPS Data:
 Date of Measurement: 07/30/2010 PDOP Reading: 5.1 GPS Instrument Operator's Name: E. J. Grabowski
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other Fish in hole
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: In 2005, after reaching TD, drill pipe and BHA was stuck in the hole. All but 74' was recovered, leaving drill collars, mud motor and bit stuck below the 9 5/8" casing. A subsequent drill string fish was stuck consisting of 4 1/2" drill pipe and 7 7/8" button bit. Top of fish is at 2,527'. Fish was cemented in place.

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
MESAVERDE	MVRD	7151	7161	11/10/2005	CEMENT	

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	14+3/4	9+5/8	36	2,619	830	2,619	0	
1ST	7+7/8	4+1/2	11.6	7,183	184	7,183	3,300	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 5 sks cmt from 2488 ft. to 2500 ft. Plug Type: CASING Plug Tagged:
 Set 20 sks cmt from 50 ft. to 0 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at 2500 ft. with 250 sacks. Leave at least 100 ft. in casing 2500 CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Oxy has obtained the use of a rig which will be in the Logan Wash area next week to plug this well; an expedited approval is requested.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Joan Proulx
 Title: Regulatory Analyst Date: _____ Email: joan_proulx@oxy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

Attachment Check List

Att Doc Num	Name

Total Attach: 0 Files

General Comments

User Group	Comment	Comment Date

Total: 0 comment(s)