

FORM
6

Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



| | | | |
|----|----|----|----|
| DE | ET | OE | ES |
|----|----|----|----|

Document Number:

400509964

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT
 Name of Operator: KERR-MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
 Address: P O BOX 173779 Fax: (720) 929-7461
 City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required, Name: MONTOYA, JOHN Tel: (970) 3974124
COGCC contact: Email: john.montoya@state.co.us

API Number 05-123-25684-00 Well Name: FRANK Well Number: 13-6
 Location: QtrQtr: SESW Section: 6 Township: 5N Range: 67W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.423219 Longitude: -104.936039
 GPS Data:
 Date of Measurement: 12/29/2008 PDOP Reading: 2.5 GPS Instrument Operator's Name: Cody Mattson
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: Production casing was cut at 250' (in a well remediation effort), pulling casing from this depth was unsuccessful and has resulted in the need to P&A the well. Cement will be circulated from 250' to surface during the P&A

Current and Previously Abandoned Zones

| Formation | Code | Perf. Top | Perf. Bottom | Date | Method of Isolation | Plug Depth |
|-----------|------|-----------|--------------|------------|---------------------|------------|
| J SAND | JSND | 8002 | 8020 | 06/17/2013 | BRIDGE PLUG | 7946 |

Total: 1 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 904 | 400 | 904 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | 11.6 | 8,130 | 990 | 8,130 | 250 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 150 with 8 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 70 sks cmt from 7900 ft. to 6800 ft. Plug Type: CASING Plug Tagged:
 Set 60 sks cmt from 4860 ft. to 4100 ft. Plug Type: CASING Plug Tagged:
 Set 30 sks cmt from 1100 ft. to 700 ft. Plug Type: CASING Plug Tagged:
 Set 65 sks cmt from 250 ft. to 150 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set 8 sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT
 Title: SR. REGULATORY ANALYST Date: _____ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

| COA Type | Description |
|----------|-------------|
| | |

Attachment Check List

| <u>Att Doc Num</u> | <u>Name</u> |
|--------------------|-----------------------------|
| 400509967 | WELLBORE DIAGRAM |
| 400509968 | PROPOSED PLUGGING PROCEDURE |
| 400509969 | WELLBORE DIAGRAM |

Total Attach: 3 Files

General Comments

| <u>User Group</u> | <u>Comment</u> | <u>Comment Date</u> |
|-------------------|----------------|---------------------|
| | | |

Total: 0 comment(s)