

Document Number:  
400606852

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10044 Contact Name: Jack Sosebee  
 Name of Operator: RED RIVER RANCH HOLDINGS LLC Phone: (303) 921-9176  
 Address: 15850 COUNTY RD 13 Fax: \_\_\_\_\_  
 City: WESTON State: CO Zip: 81091 Email: jack.sosbee@willbros.com

**For "Intent" 24 hour notice required,** Name: DURAN, JOHN Tel: (719) 846-4715  
 COGCC contact: Email: john.duran@state.co.us

API Number 05-071-08962-00 Well Number: 2-3 R68W  
 Well Name: RRR  
 Location: QtrQtr: SWSE Section: 2 Township: 35S Range: 68W Meridian: 6  
 County: LAS ANIMAS Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: PURGATOIRE RIVER Field Number: 70830

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 37.022440 Longitude: -104.964440  
 GPS Data:  
 Date of Measurement: 01/29/2007 PDOP Reading: 6.0 GPS Instrument Operator's Name: GARY L. TERRY PLS  
 Reason for Abandonment:  Dry     Production for Sub-economic     Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes     No    Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes     No    If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
VERMEJO COAL					

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
CONDUCTOR	15	12+3/4	26	24	10	24	0	CALC
SURF	11	8+5/8	32	205	75	205	0	CALC
1ST	7+7/8	5+1/2	15.5	1,744	300	1,744	20	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1108 with 2 sacks cmt on top. CIBP #2: Depth 255 with 15 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 255 ft. to 155 ft. Plug Type: CASING Plug Tagged:   
 Set 5 sks cmt from 20 ft. to 0 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Jack Sosebee  
 Title: Consultant Date: \_\_\_\_\_ Email: jack.osebee@willbros.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

### Attachment Check List

Att Doc Num	Name
400610498	WELLBORE DIAGRAM
400610499	PROPOSED PLUGGING PROCEDURE

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)