

FORM
6

Rev
12/05

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

400613861

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10439 Contact Name: Cynthia Pinel
 Name of Operator: CARRIZO NIOBRARA LLC Phone: (713) 358-6210
 Address: 500 DALLAS STREET #2300 Fax: _____
 City: HOUSTON State: TX Zip: 77002 Email: cynthia.pinel@crzo.net

For "Intent" 24 hour notice required, Name: Rains, Bill Tel: (970) 590-6480
COGCC contact: Email: bill.rains@state.co.us

API Number 05-123-14473-00
 Well Name: WEITZEL Well Number: 1-3
 Location: QtrQtr: NENE Section: 3 Township: 7N Range: 60W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.609605 Longitude: -104.071361

GPS Data:
Date of Measurement: _____ PDOP Reading: _____ GPS Instrument Operator's Name: _____

Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems

Other Re-enter & Plug

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: The scope of this work is to re-enter the old wellbore that had previously been plugged and abandoned. The well will be properly plugged and abandoned by setting cement plugs to isolate the Niobrara, freshwater zones, and setting a cement cap near the surface. Then the surface casing will have a plate wellled as final seal 5' below the surface. The old wellbore will then be buried and the surface location will be remediated.

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	6848				
J SAND	6912				
NIOBRARA	6108			CEMENT	

Total: 3 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	220	130	220	0	CALC
1ST	6+1/8	4+1/2	11.6	7,030	200	7,030	6,100	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.

CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.

CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 86 sks cmt from 5900 ft. to 5600 ft.

Plug Type: OPEN HOLE

Plug Tagged:

Set 174 sks cmt from 600 ft. to 0 ft.

Plug Type: CASING

Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft.

Plug Type: _____

Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft.

Plug Type: _____

Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft.

Plug Type: _____

Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Cynthia

Title: Pinel Date: _____ Email: cynthia.pinel@crzo.net

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type **Description**

--	--

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400613864	PROPOSED PLUGGING PROCEDURE
400613865	WELL ABANDONMENT REPORT (INTENT)
400613866	WELLBORE DIAGRAM
400613867	LOCATION PHOTO
400613870	SURFACE AGRMT/SURETY

Total Attach: 5 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)