

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400710350

Date Received:

10/16/2014

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10459

Contact Name: Taylor Heffner

Name of Operator: EXTRACTION OIL &amp; GAS LLC

Phone: (720) 9742019

Address: 1888 SHERMAN ST #200

Fax:

City: DENVER State: CO Zip: 80203

Email: theffner@extractionog.com

For "Intent" 24 hour notice required,

Name: Johnson, Randell

Tel: (303) 815-9641

COGCC contact:

Email: randell.johnson@state.co.us

API Number 05-123-08275-00

Well Name: ROCKY MOUNTAIN FUEL

Well Number: 21-32

Location: QtrQtr: NENW Section: 32 Township: 2N Range: 67W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: SPINDLE

Field Number: 77900

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.100350

Longitude: -104.917190

GPS Data:

Date of Measurement: 08/06/2008

PDOP Reading: 2.7

GPS Instrument Operator's Name: Mark Angell

Reason for Abandonment: ☐ Dry ☒ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 3870

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| SUSSEX    | 4700      | 4766      |                |                     |            |

Total: 1 zone(s)

## Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF        | 12+1/4       | 8+5/8          | 22              | 571           | 450          | 571        | 0          | VISU   |
| 1ST         | 7+7/8        | 4+1/2          | 9.5             | 5,254         | 350          | 5,254      | 3,880      | CALC   |

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4600 with 2 sacks cmt on top. CIPB #2: Depth 100 with 24 sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 86 sks cmt from 4600 ft. to 3820 ft. Plug Type: STUB PLUG Plug Tagged: ☒

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 62 sacks half in. half out surface casing from 740 ft. to 521 ft. Plug Tagged: ☒

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Taylor Heffner

Title: Production Engineer Date: 10/16/2014 Email: theffner@extractionog.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 11/14/2014

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_

Expiration Date: 5/13/2015

### COA Type

### Description

|  |   |
|--|---|
|  | Note change in plugging procedure:<br>1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU.<br>2) If unable to pull casing contact COGCC for plugging modifications.<br>3) Stub plug should be at least 50' above depth where casing was cut. If maintain circulation do not need to tag stub plug.<br>4) For 740' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 521' or shallower.<br>5) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete. |
|--|---|

### Attachment Check List

| <u>Att Doc Num</u> | <u>Name</u>             |
|--------------------|-------------------------|
| 400710350          | FORM 6 INTENT SUBMITTED |
| 400710354          | WELLBORE DIAGRAM        |

Total Attach: 2 Files

### General Comments

| <u>User Group</u> | <u>Comment</u>                          | <u>Comment Date</u>      |
|-------------------|---|--------------------------|
| Permit            | Well Completion Report dated 12/1/1975. | 10/23/2014<br>2:22:48 PM |

Total: 1 comment(s)