

FORM 6

Rev 12/05

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



Table with 4 columns: DE, ET, OE, ES

Replug By Other Operator

Document Number:

400892081

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120 Contact Name: CHERYL LIGHT
Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP Phone: (720) 929-6461
Address: P O BOX 173779 Fax: (720) 929-7461
City: DENVER State: CO Zip: 80217- Email: CHERYL.LIGHT@ANADARKO.COM

For "Intent" 24 hour notice required, Name: Rickard, Jeff Tel: (720) 305-8280
COGCC contact: Email: jeffrey.rickard@state.co.us

API Number 05-069-06273-00
Well Name: WICKED Well Number: 1
Location: QtrQtr: NWSW Section: 10 Township: 5N Range: 68W Meridian: 6
County: LARIMER Federal, Indian or State Lease Number:
Field Name: LOVELAND Field Number: 52000

[X] Notice of Intent to Abandon [] Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.412492 Longitude: -104.999702
GPS Data:
Date of Measurement: 10/23/2014 PDOP Reading: 2.2 GPS Instrument Operator's Name: OWNE MCKEE
Reason for Abandonment: [] Dry [] Production for Sub-economic [] Mechanical Problems
[X] Other RE-ENTER AND PLUG
Casing to be pulled: [] Yes [X] No Estimated Depth:
Fish in Hole: [] Yes [X] No If yes, explain details below
Wellbore has Uncemented Casing leaks: [] Yes [X] No If yes, explain details below

Details: This well was plugged and abandoned on 06/17/2000. Purpose is to re-enter to add cement above the Niobrara, cover the Shannon/Sussex and add cement to cover the surface casing shoe and all known aquifers prior to hydraulic stimulation of proposed horizontal well per DJ Basin Offset Policy dated December 16, 2013.. The 5-1/2" casing was cut and pulled from 5400' and no CBL was ever run.

Current and Previously Abandoned Zones

Table with 6 columns: Formation, Perf. Top, Perf. Btm, Abandoned Date, Method of Isolation, Plug Depth. Row 1: CODELL, 7050, 7070, 06/15/2000, B PLUG CEMENT TOP, 7000

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	32	300		300	0	VISU
1ST	7+7/8	5+1/2	17	7,175		7,175	6,500	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 80 with 25 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.

CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.

CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 320 sks cmt from 7000 ft. to 5000 ft. Plug Type: CASING Plug Tagged:

Set 420 sks cmt from 4325 ft. to 3925 ft. Plug Type: OPEN HOLE Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 220 sacks half in. half out surface casing from 500 ft. to 100 ft. Plug Tagged:

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

- a. As-built well location GPS data will be submitted on the Form 6 Subsequent Report of Abandonment.
- b. Closed loop system will be used.
- c. Re-plug and re-entry procedure attached.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST Date: _____ Email: DJREGULATORY@ANADARKO.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400892082	PROPOSED PLUGGING PROCEDURE
400892083	WELLBORE DIAGRAM
400892084	LOCATION PHOTO
400892633	SURFACE OWNER CONSENT

Total Attach: 4 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)