

FORM  
6Rev  
12/05

## State of Colorado

## Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400909226

Date Received:

10/01/2015

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 51090

Contact Name: Jim Routson

Name of Operator: LONE MOUNTAIN PRODUCTION COMPANY

Phone: (406) 245-5077

Address: P O BOX 80965

Fax: (406) 248-6321

City: BILLINGS State: MT Zip: 59108-

Email: jimroutson@lonemtnprod.com

For "Intent" 24 hour notice required,

Name: Conklin, Curtis

Tel: (970) 986-7314

COGCC contact:

Email: curtis.conklin@state.co.us

API Number 05-077-09092-00

Well Name: BAR X UNIT

Well Number: 26

Location: QtrQtr: SESW Section: 30 Township: 8S Range: 104W Meridian: 6

County: MESA

Federal, Indian or State Lease Number: D-052915

Field Name: BAR X

Field Number: 5470

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

## Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.334450

Longitude: -109.031516

GPS Data:

Date of Measurement: 12/08/2006

PDOP Reading: 0.9

GPS Instrument Operator's Name: JAMES G ROUTSON

Reason for Abandonment:

☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

## Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
DAKOTA	2944	3046			

Total: 1 zone(s)

## Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24#	321	250	321	0	VISU
1ST	7+7/8	4+1/2	11.6	3,447	240	3,447	1,860	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2890 with 10 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 2890 ft. to 3219 ft. Plug Type: CASING Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at 371 ft. with 110 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged: ☐

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

The cementing section doesn't have blanks for our proposed setting of a retainer, so i have attached a written procedure.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: James G. Routson

Title: President Date: 10/1/2015 Email: jimroutson@lonemtnprod.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: BURGER, CRAIG Date: 10/5/2015

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_ Expiration Date: 4/4/2016

### COA Type

### Description

- 1) Provide 48 hour notice of plugging MIRU via electronic Form 42.
- 2) Properly abandon flowlines per Rule 1103. File electronic Form 42 when flowline abandonment is complete.

### Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400909395	PROPOSED PLUGGING PROCEDURE
400909398	WELLBORE DIAGRAM
400909399	WELLBORE DIAGRAM

Total Attach: 3 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Addeed surface casing cement top of 0' to casing tab. CIBP at 2890' will be a CICR.	10/5/2015 9:06:18 AM
Public Room	Document verification complete 10/1/15	10/1/2015 4:01:46 PM

Total: 2 comment(s)