

Document Number:  
401049336

Date Received:  
05/17/2016

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Jason Lehman  
 Name of Operator: NOBLE ENERGY INC Phone: (970) 304-5221  
 Address: 1625 BROADWAY STE 2200 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: Jason.Lehman@nblenergy.com

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277  
 Email: jason.gomez@state.co.us

**COGCC contact:** \_\_\_\_\_

API Number 05-123-24547-00 Well Number: 35-13  
 Well Name: DYER - USX AB  
 Location: QtrQtr: SWSW Section: 35 Township: 7N Range: 64W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.524370 Longitude: -104.524400  
 GPS Data:  
 Date of Measurement: 05/10/2007 PDOP Reading: 2.3 GPS Instrument Operator's Name: PAUL TAPPY  
 Reason for Abandonment:  Dry     Production Sub-economic     Mechanical Problems  
 Other Wellhead was destroyed by a tractor  
 Casing to be pulled:  Yes     No    Estimated Depth: 2500  
 Fish in Hole:  Yes     No    If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7082	7096			
NIOBRARA	6790	6922			

Total: 2 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	896	630	896	0	VISU
1ST	7+7/8	4+1/2	11.6	7,221	730	7,221	3,208	CBL

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6740 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 2500 ft. to 2300 ft. Plug Type: STUB PLUG Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 328 sacks half in. half out surface casing from 996 ft. to 0 ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Marilyn Tucker  
 Title: Eng Tech Date: 5/17/2016 Email: marilyn.tucker@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: HICKEY, MIKE Date: 5/18/2016

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 11/17/2016

COA Type	Description
	1) Notification waived. COGCC is involved. 2) For 996' plug: pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours and tag plug – must be 846' or shallower and provide minimum 10 sx plug at the surface. Leave at least 100' of cement in the wellbore for each plug. 3) Properly abandon flowlines. Once flowlines are properly abandoned, file electronic form 42.

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
401049336	FORM 6 INTENT SUBMITTED
401049357	WELLBORE DIAGRAM
401049358	PROPOSED PLUGGING PROCEDURE
401049360	WELLBORE DIAGRAM

Total Attach: 4 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Passes permitting with the receipt of the Proposed Plugging Procedure attachment.	5/18/2016 6:31:18 AM
Public Room	Document verification complete 05/17/16	5/17/2016 4:42:23 PM

Total: 2 comment(s)