

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401061204

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10084

Contact Name: Julie Webb

Name of Operator: PIONEER NATURAL RESOURCES USA INC

Phone: (720) 3591555

Address: 5205 N O'CONNOR BLVD STE 200

Fax:

City: IRVING

State: TX

Zip: 75039

Email: julie.webb@pxd.com

For "Intent" 24 hour notice required,

Name: Duran, John

Tel: (719) 846-4715

COGCC contact:

Email: john.duran@state.co.us

API Number 05-071-07808-00

Well Name: DROWSEY DUCK

Well Number: 43-30 TR

Location: QtrQtr: NESE

Section: 30

Township: 33S

Range: 66W

Meridian: 6

County: LAS ANIMAS

Federal, Indian or State Lease Number:

Field Name: PURGATOIRE RIVER

Field Number: 70830

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 37.141000

Longitude: -104.815370

GPS Data:

Date of Measurement: 06/17/2008

PDOP Reading: 3.0

GPS Instrument Operator's Name: Adrian Valdez

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☐ No

Estimated Depth:

Fish in Hole: ☐ Yes☐ No

If yes, explain details below

Wellbore has Uncemented Casing leaks: ☐ Yes☐ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
RATON COAL	1054	1110	10/18/2011	BRIDGE PLUG	1006

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	11	8+5/8	23	289	106	289	0	VISU
1ST	7+7/8	5+1/2	15.5	1,384	330	1,384	0	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1006 with 12 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 42 sks cmt from 350 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Pick up tubing and RIH and tag CIBP at 1006'. If unable to tag CIBP at 1006', set CIBP at 1006'.
Mix 12 sacks of cement and set as a balanced plug from 1006' – 906'.
Mix 42 sacks of cement and set a balanced plug from 350' to surface.
Top off production casing if cement level is more than 4' below ground level.
Cut off casing 4' below surface
Top off production/surface casing annulus or, if necessary, run 1" tubing to at least 50' and cement back to surface.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Julie Webb

Title: Regulatory Analyst Date: _____ Email: julie.webb@pxd.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type **Description**

--	--

Attachment Check List

Att Doc Num

Name

401063125

WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

User Group

Comment

Comment Date

Total: 0 comment(s)