

Document Number:  
401105403

Date Received:

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10454 Contact Name: William Lloyd  
 Name of Operator: PETROSHARE CORPORATION Phone: (303) 500-1160  
 Address: 7200 S ALTON WAY #B220 Fax: \_\_\_\_\_  
 City: CENTENNIAL State: CO Zip: 80112 Email: blloyd@petrosharecorp.com

**For "Intent" 24 hour notice required,** Name: Helgeland, Gary Tel: (970) 216-5749  
 COGCC contact: Email: gary.helgeland@state.co.us

API Number 05-001-06713-00 Well Number: 1  
 Well Name: TSUZUKI  
 Location: QtrQtr: NENE Section: 28 Township: 1S Range: 67W Meridian: 6  
 County: ADAMS Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 39.941201 Longitude: -104.888820  
 GPS Data:  
 Date of Measurement: 01/27/2010 PDOP Reading: 2.0 GPS Instrument Operator's Name: Robert Girillego  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
J SAND	8353	8393			
Total: 1 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	173	125	173	0	VISU
S.C. 1.1	7+7/8	5	18	8,500	200	8,500	5,750	CALC
S.C. 1.2	7+7/8	5	18	1,100	200	1,100	0	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 8300 with 100 sacks cmt on top. CIPB #2: Depth 5088 with 50 sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIPB #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 8300 ft. to 7300 ft. Plug Type: CASING Plug Tagged:   
 Set 50 sks cmt from 5038 ft. to 4538 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 225 ft. with 20 sacks. Leave at least 100 ft. in casing 73 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set \_\_\_\_\_ sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:  
 Proposal to Plug and Abandon the Tsuzuki #1  
 1049' FNL & 1037' FEL  
 S28, T1S-R67W  
 Adams County, CO

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.  
 Signed: \_\_\_\_\_ Print Name: William Lloyd  
 Title: COO Date: \_\_\_\_\_ Email: bloyd@petrosharecorp.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.  
 COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_  
**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

COA Type	Description

## Attachment Check List

**Att Doc Num**

**Name**

401107045	WELLBORE DIAGRAM
401107046	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

**User Group**

**Comment**

**Comment Date**

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)