

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number: 401102001			
Date Received: 08/31/2016			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Jeanne Van Slambrouck
 Name of Operator: NOBLE ENERGY INC Phone: (303) 228-4011
 Address: 1625 BROADWAY STE 2200 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: jeanne.vanslambrouck@nblenergy.com
For "Intent" 24 hour notice required, Name: Peterson, Tom Tel: (303) 815-9641
COGCC contact: Email: tom.peterson@state.co.us

API Number 05-123-26473-00
 Well Name: STROMBERGER Well Number: 39-12
 Location: QtrQtr: SESE Section: 12 Township: 4N Range: 66W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.321342 Longitude: -104.717497
 GPS Data:
 Date of Measurement: 11/30/2009 PDOP Reading: 2.3 GPS Instrument Operator's Name: Cody Mattson
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 2500
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7266	7281			
NIOBRARA	6963	7155			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	547	270	547	12	VISU
1ST	7+7/8	4+1/2	11.6	7,439	535	7,439	3,626	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6913 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 4254 ft. to 3954 ft. Plug Type: CASING Plug Tagged:
Set 100 sks cmt from 2500 ft. to 2300 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 230 sacks half in. half out surface casing from 650 ft. to 12 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Stephanie Dionne

Title: Engineering Tech. Date: 8/31/2016 Email: stephanie.dionne@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 9/19/2016

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 3/18/2017

COA Type	Description
	1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) For the 650' plug: pump plug and displace. If surface casing plug is not circulated to surface then tag plug – must be at 497' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the casing for each plug. 3) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete. 4) Prior to initiation of plugging operations, a Bradenhead test shall be performed. If any pressure remains at the conclusion of the test or any liquids were present call COGCC Engineer for sampling requirements. Form 17 shall be submitted within 10 days.

Attachment Check List

Att Doc Num	Name
401102001	FORM 6 INTENT SUBMITTED
401102030	PROPOSED PLUGGING PROCEDURE
401102033	WELLBORE DIAGRAM
401102036	WELLBORE DIAGRAM

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Engineer	Revised location of CIBP from 6800' to 6913', and revised 261 sacks half in and half out of the surface casing to 230 sacks, and revised bottom of the surface casing plug from 700', to 650', per operator.	9/19/2016 10:35:08 AM
Public Room	Document verification complete 08/31/16	8/31/2016 10:34:30 AM

Total: 2 comment(s)