



DE	ET	OE	ES
Document Number: 401108882			
Date Received: 10/03/2016			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.
 A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10112 Contact Name: Caitlin O'Hair
 Name of Operator: FOUNDATION ENERGY MANAGEMENT LLC Phone: (918) 526-5591
 Address: 16000 DALLAS PARKWAY #875 Fax: (918) 585-1660
 City: DALLAS State: TX Zip: 75248- Email: regulatory@foundationenergy.com

For "Intent" 24 hour notice required, Name: Pesicka, Conor Tel: (970) 415-0789
COGCC contact: Email: conor.pesicka@state.co.us

API Number 05-123-14881-00 Well Number: 16-7
 Well Name: ANDREWS
 Location: QtrQtr: SESE Section: 7 Township: 7N Range: 59W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: CARETAKER Field Number: 10225

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.584110 Longitude: -104.014170
 GPS Data:
 Date of Measurement: 05/10/2007 PDOP Reading: 3.2 GPS Instrument Operator's Name: KATHY MCORMICK
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	6780	6788			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	394	300	394	0	VISU
1ST	7+7/8	4+1/2	10.5	6,945	225	6,945	6,250	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6730 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 6000 ft. with 40 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at 1600 ft. with 40 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at 500 ft. with 168 sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set 15 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Caitlin O'Hair

Title: HSE/Regulatory Tech Date: 10/3/2016 Email: regulatory@foundationenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 11/8/2016

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 5/7/2017

COA Type	Description
	<p>Prior to starting plugging operations, perform a Bradenhead Test. If pressure remains at the conclusion of the test or any liquids were present see Sampling Requirements below. Submit Form 17 within 10 days.</p> <p>Sampling requirements: If a well has a bradenhead pressure greater than 25 PSI and/or flowed liquids from the Bradenhead then sampling is required as follows: Collect a sample of both the production and bradenhead gas and submit for laboratory analysis of the gas composition and stable isotope analysis including the d13C1, d13C2, d13C3, d13C4, d13NC4 d13C5 , d13NC5, d13C6+ (if possible), and dDC1. Submit analytical results to the COGCC environmental database in an accepted Electronic Data Deliverable (EDD) format.</p> <p>If water is encountered in the bradenhead during testing then collect samples and submit for the laboratory analysis of major anions (chloride, carbonate, bicarbonate, and sulfate), cations (sodium, potassium, calcium, and magnesium) total dissolved solids (TDS), BTEX, DRO, GRO and dissolved gases (RSK 175). If there is a limited amount of water available then anions, cations and BTEX should be given first priority. Data from bradenhead water samples shall be submitted to the COGCC environmental database in an accepted Electronic Data Deliverable (EDD) format.</p>
	<p>Note changes to submitted form.</p> <ol style="list-style-type: none"> 1) Provide 48 hour notice of MIRU via electronic Form 42. 2) Shoe plug (Perf & squeeze 168 sx at 500'): Tag plug 50' above surface casing shoe if not cemented to surface as proposed. 3) Surface plug: Cement from 50' to surface in casing and annulus. 4) Properly abandon flowlines per Rule 1103. File Form 42 when done. 5) Abandoned well marker shall be inscribed with the well's legal location, well name and number, and API Number (Rule 319.a.(5)).

Attachment Check List

Att Doc Num	Name
401108882	FORM 6 INTENT SUBMITTED
401108909	WELLBORE DIAGRAM
401108911	WELLBORE DIAGRAM
401108912	PROPOSED PLUGGING PROCEDURE

Total Attach: 4 Files

General Comments

User Group	Comment	Comment Date
Engineer	Moved D-Sand plug up to 6730' (50' above perfs). Added plug at 6000' for Niobrara isolation. Added plug at 1600' for Upper Pierre aquifer isolation. Developed in 1525' deep WW located SWNE 33-8N-59W. Plug at 500'-surface was shown 2 different ways on Form. Erased the half in - half out one and left the perf & squeeze one. CBL not in scanned documents. Form 5 says TOC is 6250' by CBL. Erased wireline and cementing contractors, plugging date and cement type in section of Form titled Additional Plugging Information for Subsequent Report Only: as this information only goes on the subsequent report.	11/08/2016
Permit	As-built GPS data verified in Form 4 Sundry (Doc# 1919892, 9/20/2007); Formation and perf zone verified in Form 5 Completion Report (Doc# 225787, 9/12/1991). Permitting review complete.	10/04/2016
Public Room	Document verification complete 10/04/16	10/04/2016

Total: 3 comment(s)