

Document Number:  
401351741

Date Received:  
07/26/2017

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 75027 Contact Name: AZUCENA TORRES

Name of Operator: ROSEWOOD RESOURCES INC Phone: (970) 848-2228

Address: 2101 CEDAR SPRINGS RD STE 1500 Fax: (970) 848-2245

City: DALLAS State: TX Zip: 75201 Email: AZUCENATORRES@ROSEWD.COM

**For "Intent" 24 hour notice required,** Name: Schure, Kym Tel: (970) 520-3832

**COGCC contact:** Email: kym.schure@state.co.us

API Number 05-125-06203-00

Well Name: BROPHY, T E Well Number: 8

Location: QtrQtr: SESE Section: 13 Township: 4N Range: 46W Meridian: 6

County: YUMA Federal, Indian or State Lease Number: \_\_\_\_\_

Field Name: OLD BALDY Field Number: 60630

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.310540 Longitude: -102.455700

GPS Data:  
Date of Measurement: 08/23/2008 PDOP Reading: 5.5 GPS Instrument Operator's Name: Kevin McCormick

Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_

Casing to be pulled:  Yes  No Estimated Depth: \_\_\_\_\_

Fish in Hole:  Yes  No If yes, explain details below

Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below

Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2628	2642			

Total: 1 zone(s)

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+7/8	7	24	375	215	375	0	CALC
1ST	6+3/4	4+1/2	9.5	2,753	70	2,753	2,027	CALC

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2578 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:

Perforate and squeeze at 425 ft. with 80 sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
Set \_\_\_\_\_ sacks at surface  
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
of \_\_\_\_\_  
\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
Type of Cement and Additives Used: \_\_\_\_\_  
Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

INTENT TO ABANDON: FILL 4 1/2" CASING AND 7" SURFACE CASING FROM 425' TO SURFACE. CUT OFF CASING 5' BELOW GROUND LEVEL, WELD PLATE AND BACKFILL.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: AZUCENA TORRES  
Title: HSE & REGULATORY REP Date: 7/26/2017 Email: AZUCENATORRES@ROSEWD.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 8/10/2017

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 2/9/2018

<b>COA Type</b>	<b>Description</b>
	Bradenhead: Prior to initiation of plugging operations, a Bradenhead test shall be performed. Form 17 shall be submitted within 10 days. If there is 25 psi or greater pressure on the Bradenhead, or flowed any liquids from the Bradenhead, collect samples. See COGCC website - Operator Guidance - Bradenhead Testing and Reporting Instructions, Appendix A: Liquid and Gas Sampling.
	1) Provide 48 hour notice of MIRU via electronic Form 42. 2) Shoe plug: Tag plug 50' above surface casing shoe, if not circulated to surface. 3) Surface plug: Cement from 50' to surface in casing and annulus. 4) Properly abandon flowlines per Rule 1103. File Form 42 when done. 5) Abandoned well marker shall be inscribed with the well's legal location, well name and number, and API Number (Rule 319.a.(5)).

### **Attachment Check List**

<b>Att Doc Num</b>	<b>Name</b>
401351741	FORM 6 INTENT SUBMITTED
401354057	WELLBORE DIAGRAM
401354059	WELLBORE DIAGRAM

Total Attach: 3 Files

### **General Comments**

<b>User Group</b>	<b>Comment</b>	<b>Comment Date</b>
Public Room	Document verification complete 08/01/17	08/01/2017
Permit	WBD for incorrect well. Returned to draft.	07/25/2017

Total: 2 comment(s)