

Document Number:
401522213

Date Received:
01/22/2018

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Sonu Choudhary

Name of Operator: NOBLE ENERGY INC Phone: (720) 939-2574

Address: 1001 NOBLE ENERGY WAY Fax: _____

City: HOUSTON State: TX Zip: 77070 Email: narayan.choudhary@nblenergy.com

For "Intent" 24 hour notice required, Name: Montoya, John Tel: (970) 397-4124

COGCC contact: Email: john.montoya@state.co.us

API Number 05-123-17345-00 Well Number: D 30-5

Well Name: HETTINGER

Location: QtrQtr: SWNW Section: 30 Township: 3N Range: 64W Meridian: 6

County: WELD Federal, Indian or State Lease Number: _____

Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.197415 Longitude: -104.600648

GPS Data:
Date of Measurement: 07/10/2009 PDOP Reading: 2.2 GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: 870

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7043	7053			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	637	445	637	10	VISU
1ST	7+7/8	3+1/2	7.70	7,206	355	7,206	6,140	CBL
S.C. 1.1				4,800	190	4,800	3,795	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6993 with 15 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 30 sks cmt from 4650 ft. to 3950 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 2500 ft. with 180 sacks. Leave at least 100 ft. in casing 2400 CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 295 sacks half in. half out surface casing from 920 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

DISCREPANCY IN PROD CSG BTM DEPTH: INITIAL CMLPT RPT 7198', WBD IN 2005 IS 7206' WHICH MATCHES DRL RPT.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Diane Blair

Title: Engineering Technician Date: 1/22/2018 Email: diane.blair@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 3/8/2018

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 9/7/2018

COA Type	Description
	<p>Venting</p> <p>Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Bradenhead Testing</p> <ul style="list-style-type: none"> • Prior to the start of plugging operations, a bradenhead test shall be performed and reported if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations. • If any of the following conditions exist then sampling of all fluids is required and sampling methods shall comply with Operator Guidance – Bradenhead Testing and Reporting Instructions, Appendix A: Liquid and Gas Sampling as found on the COGCC website, cogcc.state.co.us. <ul style="list-style-type: none"> 1) The initial pressure measurement on the bradenhead is greater than 25 psi, prior to blowing down any liquid or gas from the bradenhead valve, or 2) Pressure remains at the conclusion of the test, or 3) Any liquids are present anytime during the test. If so, then stop the test as soon as liquids are present and sample before resuming the test.
	<p>Plugging</p> <ul style="list-style-type: none"> • Provide 48 hour notice of plugging MIRU via electronic Form 42. • If there was pressure on the surface casing at any time during the pre-plugging bradenhead test then wait 8 hrs after pumping squeeze at 2500'+- and check for fluid migration or shut-in pressure on the well. Contact COGCC Engineer for revised plugging orders if well is not static at this time prior to continuing with plugging operations. • Check for fluid migration or shut-in pressure on the well prior to pumping any plug (open hole, annular or casing) that isolates deepest aquifer or the surface casing shoe (whichever is deeper). Contact COGCC Engineer for revised plugging orders if well is not static at this time, prior to continuing with plugging operations. • Tag required if the shoe plug, or combined stub/shoe plug, is not circulated to the surface and top of cement must be 50' into the shoe, or 50' above the cut, whichever is shallower. • Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. All other cement plugs, without mechanical isolation, shall have at least 100' of cement left in the casing. • Properly abandon flowlines as per Rule 1103.
	<p>Post Plugging Reporting</p> <ul style="list-style-type: none"> • Form 17 Bradenhead Test Report shall be submitted within 10 days of the test. • File electronic Form 42 once flowline abandonment is complete. • If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.

Attachment Check List

Att Doc Num	Name
401522213	FORM 6 INTENT SUBMITTED
401522265	WELLBORE DIAGRAM
401522266	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group	Comment	Comment Date
Public Room	Pass	02/09/2018

Total: 1 comment(s)